

n<sup>o</sup> 1595147.

a.c.2 m.s. Snowball

Notes.

# LANCASTER

## The Patent 'LOXON' Loose-leaf BINDER

Patents Nos. 237854 and 364810



### LIST OF STOCK SIZES

Ref. No.	Size of Leaf
S1	8 x 6½
S2	9½ x 7½
S3	10½ x 8
S5	13 x 8

Reference for  
re-ordering

53 S

### HOW TO USE THIS BINDER



- 1.—To insert or withdraw leaves, open the Binder at the place where the leaves are to be inserted or withdrawn, then draw the two sets of spiral and straight eyes through to the place and fit.



- 2.—Insert or withdraw the leaves and join the leaves up again.




- 3.—Draw the leaves tight and wind them up under the spiral springs.


HUNT & BROADHURST LTD., OXFORD

SPAN - 102'

LENGTH - 69'

HEIGHT - 20' approx.



ANTI-ICINGICING CONDITIONS

Between +4°C & -12°C

Critical Range 0°C & -7°C.

When moisture is present.

Use fluid de-icing D.T.D 406 A.

Average setting for needle valve  
 $1\frac{2}{3}$  open.

Consumption of pump at this setting  
 pumping one per min - 2 pts per R.T.

## LANCASTER.

MARK I - Powered by 4 Merlin XX or XXII engines

" II - 4 Hercules IV engines

" III - 4 Merlin 28 or 38 engines. (Stramberg all)

## FUSELAGE CONSTRUCTION.

All metal stressed skin semi-monocoque type.  
The skin is Alclad and is supported by  
a system of formers and struts. There are  
52 formers in all "K to A" omitting "I" followed by  
numbers 1 to +2 working from nose to tail, and  
spaced about 18° apart. The fuselage is built up  
in 5 sections, these sections are joined at transport  
joints.

The leading edge of the centre section is  
ringed on top of the front spar.

## MAINPLANE CONSTRUCTION.

Cantilever type with detachable wing tips and  
split trailing edge flaps.

## EMERGENCY EXITS.

Three escape hatches No.1. in the canopy above  
the pilot No.2:- above the rest bed No.3 just  
forward of the flare chute. To release these  
hatches turn the handle clockwise and push out.  
The main PARACHUTE EXIT is in the floor of the  
bomb aimer's compartment.

open by pulling the metal ring inwards. In extreme emergency certain of the crew will bail out through the main entrance door.

#### POSITION OF COMPONENTS

1. Ground to Flight Switch.

Starboard side between the front seat and the bulkhead doors.

2. Crash Axe.

(a) Port side opposite the entrance door.

(b) Starboard side opposite the rest bed.

(c) Starboard side near the Pilots Panel.

3. First Aid Kit, Fuel and Oil Dipsticks and F.E.'s tool satchel.

Starboard side just aft of the entrance door.

4. Control Locking Gear.

Starboard side opposite the rest bed.


5. Very Pistol.

In a leather cup on top of the front seat. Fixing point in the roof above.


6. Signal Cartridges.

On Starboard side near the front seat.

## CONTROLS.




RUDDERS. STOP IS FORWARD  
OF PEDALS.



## ELEVATORS.

STOP - FORE & AFT OF C. COLUMN.

CONTROLS ROUND PILOT'S SEAT.



## FUEL JETTISON

AIR INTAKE

Bomb  
DOORS


PILOTS  
SEAT.

FLAPS

LEFT TRIMMING TAB  
PEDESTAL

L/C

## F.E.'s PANEL



### ELEVATOR & RUDDER CONTROLS.

Push-pull tubes running down port side of fuselage. Top tube Rudders. Bottom tube Elevators. Made of Dural and supported in Tufrol Bungs. Squared Sections just aft of the rear spar and where the tubes end opposite the balance door prevent torque.

### AILERON CONTROLS.

A system of chains, cables, and tie-rods, running down the Port side of the fuselage to the Rocking Levers on the rear face of the Rear Spar. From here push pull tubes are linked to the ailerons themselves.

### TRIMMING TABS.

Fitted to ailerons, elevators and rudders and controlled from a pedestal seat to the pilots' seat, under the control. Trimmed control cables must never be crossed.

### BALANCE TABS.

Automatic in operation, and appearing to move in the opposite direction to the control surface. Fitted to the ailerons, and elevators. The rudder being horn balanced.

## OXYGEN SYSTEM.

### POSITION OF COMPONENTS.

AMENDED F/GT. ADAMS.

1. External Charger Valve. - Former 7 and 8. Port side.  
Centre of Bomb-bay. Next to No. 13 Bomb-slip.
2. Bottles.  
15 underneath the Rest Bed. 1800 lbs/H<sup>2</sup> pressure.  
capacity 750 litres. Supply of oxygen will  
last approx. 8-10 hrs at 20,000 ft. Each bottle  
is bound with wire. Supply of oxygen remaining  
is entered on the log on return to base.
3. Main Supply Cock.  
At foot of rest bed.
4. Mark 10A Master Regulator.  
Starboard side of pilots panel.
5. Cut-off Valve, flow indicator & Economiser.  
One at each crew position and also at the  
rest bed, flare chute and elsewhere.  
N.B. Pilot has no cut-off valve and no flow  
indicator and the F.E. has no flow indicator.

### FUNCTIONS OF COMPONENTS.

#### Regulator:-

Reduces the pressure and regulates the flow.  
The contents gauge will not register until the  
master cock underneath it is turned on.

#### Economiser.

Effects a 50% saving in the use of oxygen by  
only delivering as the wearer breathes in. As the  
wearer breathes out oxygen is stored in a fabric bag

ready for the next breath.

#### TESTING ECONOMISERS.

1. Turn on the main supply cock.
2. Turn on the master cock on the regulator.
3. Check the gauge reading.
4. Set the regulator at emergency and then turn back to read 30,000 ft.
5. Remove economies hose from cut-off valve.  
5 to 7 puffs per minute should be felt or heard.

Note:- Always smell the oxygen. A musty smell denotes presence of moisture in the system.

#### USE OF OXYGEN.

##### DAYTIME:

All aircrew use oxygen from 15,000 ft. Use from 10,000 ft. in extremely cold weather or if flying for more than an hour at this altitude.

##### NIGHTTIME:

All aircrew use oxygen from 4,000 ft. and continue to use it back to base.

#### SETTING REGULATOR.

Initial setting is 15,000 ft. and the regulator must be kept at least a clear 5,000 ft. above the altitude of the aircraft. 15,000' next setting 25,000.

#### IMPORTANT POINTS.

1. Always test equipment before flight.
2. Carry the correct type of mask.

3. Check the adaptors for the portable bottles.
4. If the needle on the contents gauge approaches the red mark warn the pilot to descend below oxygen height.
5. Remove bobbins from cut-off valves before flight.
6. Main supply cock closed when charging the system.
7. Revers lubricate with oil or grease.
8. All oxygen cocks should be fully open or fully closed.

#### PORTABLE BOTTLES

Seven are fitted.

1. Starboard side B.A.'s compartment.
  2. At rear of pilot's seat or on the floor near the F.E.'s panel.
  3. On the Nav's chair support.
  4. Starboard side just aft of the front spar.
  5. Starboard side just forward of the rear spar.
  6. Starboard side near the mid upper turret.
  7. Starboard side just forward of the rear turret.
- These bottles are of 75 litres capacity charged at 18.00 lbs/lb" and lasting 10 minutes.

An "On-Off" cock, reducing valve, bayonet union, recharging point and gauge reading minutes of supply are fitted on top of each bottle. The needle is luminous and two luminous dots are marked at the bottom of the scale.

## ECONOMIZERS:

1 - F.Tank.  
1 - B.A's (Power Stn)

2 - UNDER PILOTS PLATE.

1 - STEW. SIDE (N.W.)

1 - W/W/P (P.S.)

1 - REST BED (R.B.)

1 - MID. LINER.


1 - AIRMAN BOTT.

1 - PARACHUTE CHUTE (MID-UNDER)


1 - ELSAN

1 - R.TANKER.

FILTER




NITROGEN.



PRESSURE 1800-2000.

> - N.R.V.s

E.C.V.



## NITROGEN SYSTEM.

Supplies nitrogen gas to the six fuel tanks to fill the space above the liquid petrol.  
Minimises fire risk.

### BOTTLES.

12 In all, seven on the front face of the rear spar and five on the starboard side of the fuselage centre sections, painted grey with black cap.

### MAIN SUPPLY COCK.

Starboard side fuselage centre section near the five bottles

### PRESSURE GAUGE.

Next to the main supply cock

### E.C.V.

Starboard side of the bomb bay, accessible from the outside. Next to formers H~

### PALMER FILTER AND REDUCING VALVE.

One in each underscarriage nacelle on the rear face of the front spar.

### SHIFTER VALVES.

Double acting relief valves one in each vent pipe.

### FUNCTIONS OF COMPONENTS.

PALMER VALVE: Reduces pressure to 15-25 lb/in<sup>2</sup>

AMAL VALVE: Reduce to 4 to 8 lb/in<sup>2</sup> above atmospheric.



SHIFTER VALVES: Set to allow escape of nitrogen at about 1 lb/in<sup>2</sup> above atmospheric.

Permits entry of air if pressure in the tank drops.

PROCEDURE.

1. Turn supply cock on before starting.
2. After half an hour flying check the drop in pressure (not to exceed 100 lbs)
3. Check every half hour.
4. At landing pressure should read at least 200 lbs/in<sup>2</sup>.

# CABIN HEATING SYSTEM.



TURN OFF when (a) Starting. (b) Inboard engine feathered or on fire.  
 (c) Fire inside fuselage.

## General.

Radiators are connected to engine coolant of inboard engines. Pet cocks are provided to vent the system of air.

## FIRE EXTINGUISHERS.

### ENGINE INSTALLATIONS.

4 - 3pt. size bottles one to each engine.

#### INBOARD.

On the rear face of the front spar in the nacelle.

#### OUTBOARD.

On the engine sub-frame.

Each Bottle contains Methyl-Bromide in liquid form under pressure (60lb/in<sup>2</sup>).

The distributing pipelines encircle the engine and lead to the air intake

#### OPERATION.

An electrically fired explosive charge breaks the seal on the bottle and the Methyl-Bromide reduces the engine temperature and smothers any flames.

#### SWITCHES.

4. 4 - Push buttons mounted on the Plots Panel with red covers.

4. Gravity switch on Starboard side of Bomb-Aimers Compartment which operates all the bottles when the a/c turns over with the a/c locked down.

3. Inertia Switch on Starboard side of Bomb-Aimers Compartment which operates all bottles when retardation exceeds 6g. (i.e. crash landing.) This switch has a spring loaded plunger

on the top surface for test purpose.

NOTE:- Flare switches are fitted but not wired up

#### PORTABLE EXTINGUISHERS.

1. Starboard side of fuselage nose on handling rail.
2. Port side just behind Pilot's seat.
3. Front end of navigator's table.
4. Starboard side above the front seat 2pt.
5. Starboard side near the mid upper turret.
6. Port side near the rear turret.

All 1 pint size except No.4 which is 2pts.

#### OPERATION.

Strike the plunger on No.4 bottle and on all others turn the handles anti-clockwise.

All the pint size bottles can be shut off when partially used.

#### ENGINE FIRE IN FLIGHT.

1. Captain warns crew.
2. Pilot and F.F. feather the engine.
3. When engine has stopped operate the ext.
4. Do not restart the engine.

#### FUSELAGE FIRE IN FLIGHT.

1. Warn the crew and take oxygen. Put on goggles.
2. Set the regulator at emergency.
3. Close all windows and openings to prevent draught.
4. Use portable extinguishers.

5. When the fire is out the poisonous fumes must be cleared.

### DINGHIES AND DITCHING.

#### TYPE 'J' Mk. III.

Bouyancy factor 3,000 lbs. Pressure 1½ lbs. Inflated with C.O.2 and carries seven to eight persons.  
Stowage Starboard centre section near the trailing edge.

#### RELEASES.

1. Electrical, by a circuit completed when water enters the 2 immersion switches in the boat-simcos compartment, one each side.
2. Manual, by cable carried in a red conduit tube running down the wof of the aircraft on the starboard side I operated from 3 positions inside the aircraft, - above the flap-jack, by the rear ditching exit and above the entrance door.
3. An external release is fitted on the starboard side next to the leading edge of the tailplane.

#### EQUIPMENT ON THE DINGHY.

1. C.O.2 Cylinder gas charge 6 lbs 7ozs.
2. Operating head type 'H.' Set when the green spot is showing through the cover.
3. Tapping up valve, incorporating a 1¾lb relief valve.
4. Bellows
5. Leak Stoppers. 3 sets of 3.

- X
6. Rescue Quoit and line.
  7. Compass.
  8. Floating knife.
  9. Drogue or sea anchor.
  10. Rope ladders, handling lines, stabilizing pockets and tops lines.

#### EQUIPMENT TAKEN INTO DINGHY.

1. Emergency pack type 7.
2. Rocket aerial. A 200 ft aerial fired from a pistol and used to increase the range of the radio 10 m.p.h. windspeed or over.
3. Dinghy Radio.
4. Verry Pistol and Signal cartridges.

#### CONTENTS OF PACKS.

4. TYPE 5. Makor canvas pack with zipp fastener.
  - (a) 7 tins of emergency rations. (M.R.II)
  - (b) 10 tins of water.
  - (c) 1 drinking cup.
  - (d) 1 pt. paddles. Glove type.
  - (e) 10 tins of signal cartridges. 3 per tin.
  - (f) 1 Signal Pistol 1"
  - (g) 1 fluoresceine sea marker.
  - (h) 1 tin of matches.
  - (i) 1 first aid outfit.
  - (j) 1 W.T. Aerial Mast.
  - (k) 1 Loading Coil. (n) 1 4" Heliograph.
  - (l) 1 Distress Flag. (n) 1 Sponge. (o) 1 Weather Apon.

TYPE 7. Valve Type.

18 Tins of Water.

18 Tins of Signal cartridges. 3 per tin.

2 Fluorescine sea markers.

STOWAGE:

Starboard side aft of the rear seat.

Skull caps are personal issue and floating torches are carried on the Mae West. Dinghy Radio and 2 kilo aerial stowed above the rest bed.

TYPE Q DINGHY.

A sailing dinghy gas pressure 15 lb/ft<sup>2</sup>. Buoyancy 3,000 lbs and holds 7 to 9 persons. The buoyancy tube is in 2 parts joined amidships and an inflatable thwart tube gives lateral rigidity. This tube must be inflated by bellows. A canvas keel is extended by the erection of the mast and a rudder can be fitted at the stern.

STOWAGE & RELEASES.

As for "J" type.

EQUIPMENT ON DINGHY.

1. CO<sub>2</sub> Cylinder containing a 7lb gas charge.
2. Operating head type "H".
3. Popping up valves. On buoyancy tube port side.
4. Leak stoppers and repair outfit.
5. Rescue line and quoit. Port side at bow.
6. Floating knife. next to CO<sub>2</sub> cylinder.

7. Hauling in line amidships
8. Drogue, in a pocket on the floor at the stern.
9. Maps. A set of 18 and one navigational chart. Slowed at the stern with instruction book.
10. Compass, at stern next to map storage.
11. Weather cover, in 2 sections with blue undersurface for camouflage.

EQUIPMENT IN THE BAGS ON THE HAULING IN LINE.

4. Bellows and fishing tackle.
5. Telescopic mast and rigging lines.

Foward - Yellow      Aft - Brown

Starboard - Green      Port - Red

3. Sails, Halyards, canvas rudders.

These bags are in the dinghy stowage and a pair of glove type paddles are also attached to the hauling in-line.

Type 5 pack is attached to the dinghy by a lanyard.

TYPE K Dinghy.

A 1 man dinghy usually attached to the man over or parachute harness. Inflated with CO<sub>2</sub> pressure 2 to 3 $\frac{1}{2}$  lbs./sq. in. buoyancy 320 lbs. Gas charge 12 ozs. Released by unscrewing the operating head slowly.

EQUIPMENT.

- |                        |                    |                            |
|------------------------|--------------------|----------------------------|
| 1. Topping up bellows. | 4. Balot.          | 7. Water Pocket and        |
| 2. " " valve           | 5. Drogue.         | trip line.                 |
| 3. C.O.2 Cylinder.     | 6. Thwart Pockets. | 8. Weather apron and hood. |


## CONTENTS OF SPECIAL PACK.

1. Rations.
2. Compass.
3. Distress Signals.
4. Lead Stoppers.
5. Sail and mast.
6. thwart paddles.
7. Heliograph.

## FLIGHT ENGINEER'S DITCHING DRILL.

Signal Received. - "Dinghy, Dinghy, Prepare for ditching" and by the call light DAH DIT DIT (3 times).

1. Acknowledge, "Engineer ditching."
2. Remove parachute harness.
3. Assist pilot. (Safety harness, lowering flaps etc.)
4. Jettison pilots' hatch.
5. Collect the axe, and move to ditching position.
6. Remove collar and tie, retaining helmet for protection.
7. Inflate Mae West. If heavily built do not inflate the Mae West fully.
8. Lie on the rest bed, face up, braced between the back rest and the bulkhead doors. Intercoms plugged in and safety strap in position. Right hand on strap release; left hand around head.
9. On receiving the order from the pilot



## PNEUMATICS.

### POSITION OF COMPONENTS.

1. Compressor: - Starboard inner engine A BANK.
2. E.C.V.: - On the small wooden panel. stbd. up. Racelle.
3. Oil and Water Trap: - Ditto.
4. Regulator: - Rear face stbd. inner engine bulkhead.
5. Air Bottle: - Roof of B.A's compartment.
6. Air Filter - 4 way union - D.R. Valve: - Port side B.A's compa
7. Maintaining Valve: - B.A's comp. just below 4 way union.  
Originally one on each engine bulkhead.
8. Pressure Reduction Valves - 4: - 1 on front face of each engine bulkhead.

### FUNCTIONS OF COMPONENTS.

1. Regulator. This regulates the pressure in the system to between 320, and 270 lbs/ $\text{in}^2$ . As soon as the pressure has been built up a by-pass valve opens in the regulator allowing the air from the compressor to go to atmosphere. If this by-pass valve does not open a safety valve will open at a pressure slightly above normal. A non-return valve in the outlet connection traps the air already in the system.
2. DUNE RELAY VALVE.
  1. Reduces the brake pressure to a controlled maximum of 80 lbs/ $\text{in}^2$ .
  2. Provides differential braking action.
  3. Gives progressive braking, according to the movement on the hand control.

### 3. MAINTAINING VALVE.

Set to close if a leak occurs and causes the pressure to drop to 105 lb/ft<sup>2</sup> ± 5 lb/ft<sup>2</sup>. This will trap the last 100 lbs of air pressure for use in the brake <sup>surface</sup> but the other services will be out of action. This only applies where the leak is beyond the pressure maintaining valve.

### 4. PRESSURE REDUCING VALVES.

Reduces the pressure to 220 lbs per sq. in. for operation of the auxiliary services.

### 5. RADIATOR SHUTTERS.

Operated by an electro-pneumatic ram which is opened and closed by air pressure. Automatically controlled by a thermostatic switch so that they open when the coolant temp is 105°C. and close at 99°C.

### OVERRIDE SWITCHES.

With 150 lb/ft<sup>2</sup> or more in the air bottle the rad shutters may be opened at any time by these switches cutting out the thermostatic control. Use if during ground running, taxying or marshalling for take-off the coolant temp reaches 90°C or the oil temp 80°C. At take-off inboard shutters are on auto and outboard open by override switches.

### SUPERCHARGER + I.C.O. RAMS.

(Mk III aircraft) Operated by electro-pneumatic rams spring loaded to the extended position (ie:- 1/4 gear

position and engine running position) These same are closed by air pressure (i.e. S gear, and I.C.O.)

NOTE:- The control is by switches on the pilots panel. (centre) and the red warning light at the side of the s/c. switch will show if the u/c is lowered (i.e. locked down) with "S" gear in. The switch works off starboard u/c leg only.

#### TESTING BRAKES.

1. Check pressure in the main supply (minimum 200 lbs)
2. Apply the brakes fully with rudder pedals central. Pressure should be 80 lbs to each brake.
3. Leave for 15 minutes with parking catch on and then check for signs of a leak.
4. Check that both brakes release quickly.
5. Check the differential action, with fully port rudder starboard brake needle should read zero. Operate brakes just after T.O and prior to landing.

#### TEST FOR S/C + I.C.O.

Operate these switches about 6 times up and down. Pressure should drop about 10-12 lbs.


#### ADJUSTMENT OF BRAKES.

6. Brakes applied, pedals central, and unequal pressures shown on the gauge.

Check the position of the pointers on the D.R.V. and if necessary adjust on the rod. If pointer is central and brakes central a new valve is needed.

2. Maximum pressure incorrect.

Adjust on the cable, screwing OUT to INCREASE pressure. Where this adjustment is for more than 10 lbs. change the relay valve.



## FUEL SYSTEM.

6 self-sealing tanks numbered 1, 2, and 3, port and starboard. The number 3 tanks have no direct feed to the engine. The total capacity is 2,154 gallons and the system consists of separate port and starboard installations connected only by a cross balance line in which is fitted a cock. This cock is normally closed and the two halves of the system quite independent. 1077

In the original system immersed pumps were fitted the delivery pipe leading from the top of the tanks. To improve gravity feed separate lines including non return valves were fitted. On some Mk. I and all Mk. IV aircraft Pulsometer Pumps are fitted underneath the tank each pump incorporating a gravity feed.

### BESTER PUMPS.

A. Immersed Type - Electronically operated impeller type pumps with centrifugal action. Delivery 380 gallons per hour. Will build up a pressure of 12 lbs/in<sup>2</sup>.

B. Pulsometer Type. - Similar to the immersed pump with approximately the same delivery will build a slightly higher pressure. (15 lbs/in<sup>2</sup>)

### TESTING PUMPS

1. Ground / Flight switch to FLIGHT.
2. Plug in an ammeter, unless fitted on the panel.

3<sup>y</sup> Place the booster pump switches one at a time to the up [TEST] position. Each immersed pump should give a reading of 2 to 4 amps. Each Pulsometer Pump should give a reading of 4 to 7 amps.

Note: Always avoid running these pumps dry.

#### OVERLOAD TANKS.

One or two 400 gallon tanks may be fitted in the bomb-bay, their contents being transferred into the No 1 tanks when space is available. The two selector cocks are on the floor, behind the front seat Port side and two booster pump switches and contents gauges are on a small panel in the canopy above the F.F.

#### REFUELLING.

1. If maximum bomb-load is carried fill numbers 2 tanks and put the remainder in No. 1.

During re-fuelling make a practical test of No 3 tank boost pumps by transferring a little petrol.

#### PRIMING.

A 16-gass priming pump and 2 priming cocks are fitted in each nacelle the pump at the bottom of the wooden panel and the cocks above the panel behind the ledge. A three-way cock for priming with high

volatile fuel is now being fitted above the priming cocks.

#### FUEL PROCEDURE.

For Starting, Take-off, and Normal Flight.

1. Gross balance cock off.
2. Main Panel switch ON. (check warning lights etc.)
3. Check the fuel state making corrections for tail down.
4. Test all booster pumps by ammeter.

WITH ALL TANKS FULL.

1. Start on No1 tanks with No 21 Booster Pumps on.
2. When all engines are running change to No2
3. Change back to No1 and run up. Test No1 gravity feed.
4. Take-off on No2 Pumps on for No1 and No2.
5. At safe height (below 17,000 ft) switch all booster pumps OFF.
6. Fly for 1hr 20 mins on No2 tanks.
7. Change to No1 and transfer from 3 to 2.
8. Use No1 until equal to No2 (370 gals. approx)
9. Use alternate tanks to maintain balance  
(leave the last 100 in No2)
10. Drain No1 so that No2 is in use when landing.

\* No3 tank empty, No2 full. No1 over 383 gals. \*

1. Start on No21 tanks with No21 Booster Pumps ON.
2. When all engines are running change to No2
3. Change back to No1 tanks
4. Take-off on No2 Pumps on for No1 and No2.
5. At safe height (below 17,000 ft) switch all booster pumps OFF.  
1000'

6. Change to No 1 tanks after 10 mins. (This leaves 40 gals space in No 2)

7. Use No 1 until equal to No 2 and then alternate hourly.

With 400 gals or less in No 1 and No 2 full.

1. Take-off and Run for 1 hr on No 2.

2. Change to No 1 and change over hourly.

#### Use of BOOSTER PUMPS.

1. Starting: No 2 pump ON.

2. Take-off: No 1 and 2 ON.

3. Steep climb: Tanks in use.

4. Flight above 17,000 ft: Tanks in use.

5. Flying over target: No 1 and 2 ON. or in Evasive Action

6. Making a tank change: Tank pump to which change is to be made.

7. Landing: With fuel in 1 and 2. all pumps ON.

8. Running 4 engines off 1 tank. Tank pump for tank in use ON.

#### PROCEDURE OVER THE TARGET.

1. 4 booster pumps ON.

2. Select tanks containing the most fuel.

3. Keep a close check on warning lights and contents gauges.

4. If a slight leak occurs to a tank in use or serious damage to a tank not in use take no action until clear of the target.

5. Should serious damage occur to a tank in

use, warn the pilot and change tanks.  
Take balancing action after leaving the target.

#### TESTING SELF-SEALING PIPES.

5,000'.

On the return journey at safe height run all four engines from each tank in turn. Engines at maximum cruising 2650 +7 for 1 min.

#### FUEL JETTISON.


##### PROCEDURE.

1. Warn the Rear gunner
2. Reduce speed to 115-150 mph.
3. Lower flaps 15°
4. Available crew stand by with extinguishers.
5. Operate jettison control (left and turn anti-clockwise)
6. After fuel is gone return the control to normal.


##### GENERAL.

1. A 1,000 gallons can be jettisoned.
2. Any part of this quantity can be jettisoned.
3. Use when ditching, crash-landing, etc.

FUEL JETTISON.



LANCASTER HYDRAULICS.



## HYDRAULICS.

### COMPONENTS.

#### 1 RESERVOIR

On top of the front spar on the port side. A 7 gallon tank (2 gals fluid, 5 gals air space). is filled to the top of the gauge filter in the filler neck with engines off, undercarriage down and bomb doors down. Fluid used is anti-freezing mineral oil. The system contains 19½ gallons.

#### 2 DISTRIBUTOR BLOCK.

Directly below the reservoir. Has a slide which is pulled out for pressure test.

#### 3 GROUND TEST COUPLINGS.

2 in each nacelle on the wooden panels.

#### 4 Avery Couplings.

2 on each inboard engine bulkhead.

#### 5 ENGINE DRIVEN PUMPS.

One driven by each inboard engine. Dowty Spur gear type. With approximately delivery of 8 gals a minute each. The shaft shears at 2,500 lbs pressure.

#### 6 FILTER AND Aero-Cut-Out

Rear Face of the Front Spar, Port side. The filter element is spring loaded to allow the fluid to bypass if there is an increase of 5-6 lbs/in<sup>2</sup> in pressure due to a dirty filter.

## 2. ACCUMULATOR & HAND PUMP

In the Port side of the fuselage between the front spar and the bulkhead door. The hand pump contains a relief valve set to open just above 850 lbs/in<sup>2</sup>.

## 3. THERMAL EXPANSION VALVES.

- (a) Undercarriage circuit: 1 double-acting type fitted just above the jacks in the port nacelle.
- (b) Bomb Doors Circuit: 1 double-acting type between the jacks on the rear bomb-bay bulkhead.
- (c) Flap Circuit: 2 single acting valves fitted at the flap selector unit.

All these valves open at 1200 lbs per sq.in. pressure.

## FUNCTIONS OF COMPONENTS.

- 1. RESERVOIR. Provides a means of storing the fluid to extend unbalanced jacks, allows for expansion of fluid, and compensates for any small leaks.
- 2. AUTOMATIC CUT OUT. Provides a means of unloading the E.D.P's when no hydraulic jacks are moving. When the pressure in the pressure line drops to 220 lbs per sq.in. the A.C.O. cuts in and allows the pumps to deliver to the selected jacks. When these jacks have reached the end of their travel pressure builds up, the A.C.O. cuts out and the idling circuit is restored. (850 lbs/in<sup>2</sup> out, 220 lbs/in<sup>2</sup> in)
- 3. Accumulator. This reduces the rate at which pressure builds up or drops.

- (a) It prevents hammering of the A.C.O. and
- (b) shock loads on the E.D.P.s during the operation of small jacks.
- (c) supplies the initial flow of oil to start the movement of the large jacks.
- (d) Absorbs all shock loads on the system.

#### TESTING ACCUMULATOR AIR PRESSURE.

- With engines stopped make a selection to allow the fluid from the accumulator to be discharged into the jacks, gauge reading should then be 220.00/11".

#### UNDERCARRIAGE LOCKS.

##### DOWN POSITION.

1. Hydraulic lock by the N.R.V. at the selector.
2. Mechanical lock by latches engaged by the final down movement of the jacks.
3. Geometics.

##### UP POSITION.

1. Hydraulic by the same N.R.V.
2. Mechanical latches.

#### UNDERCARRIAGE INDICATORS.

On the port side of pilot's panel with a master switch near the ignition switches. A change over switch for a duplicate set of green bulbs is fitted either below the master switch or in the centre of the indicator itself.

#### UNDERCARRIAGE WARNING LIGHTS. FUSE 13.

1. locked up - NO LIGHTS.

2. UNLOCKED - RED LIGHTS.
3. Locked Down - GREEN LIGHTS.


WARNING HORN.

This will sound if either inboard engine is throttled back to less than a  $\frac{1}{2}$  open and the undercarriage is not locked down. A test button and red warning light are fitted on the cockpit rail behind the pilots seat.


FLAP INDICATOR.

Now fitted bottom centre of the panel together with a master switch.

EMERGENCY LOWERING.  
U/C AND FLAPS.



EMERGENCY LOWERING  
BOMB DOORS.



## EMERGENCY LOWERING.

### POSITION OF COMPONENTS.

1. E.C.V. - In the roof of the bomb-bay just forward of No. 13 bomb-slip\*. Between F.748 Port Side.
2. BOTTLES. - 2 on the rear face of the front spar. Pressure 12,00 lbs/ft<sup>2</sup>.
3. AIR CONTROL VALVE. - Starboard side of fuselage near the front spar. Controlled from a handle just forward of the F.E.'s panel. Hold this handle in position until the undercarriage is down.
4. EMERGENCY AIR VALVE & EMERG. AIR N.R.V. - Fitted in each nacelle between the u/c jacks.

### NOTES ON E. LOWERING OF U/C.

1. The flap selector must be neutral before releasing the air.
2. When the u/c is down operate flaps as required, lowering a few degrees at a time.
3. The flaps cannot be lowered without lowering the u/c.
4. The u/c hydraulic selector need not be down.
5. After using air avoid making any hydraulic selections.
6. If the emergency air is released while the u/c is standing on the ground it will be obvious by a drop in pressure and a pool of oil under the vent pipes in each nacelle.

### Bomb Door Emergency Lowering.

1. Select bomb doors open and operate emergency air control
2. The doors can be opened and closed by air pressure. (4 to 5 times).
3. Hold the air control open for about 3 seconds
4. Make sure that the supply cock on the air bottle is open before take-off.

### POSITION OF COMPONENTS.

AIR BOTTLE. front face of the bomb-bay Port side.

AIR CONTROL. BA's compartment next to anti-icing tank.

### UNDERCARRIAGE INDICATOR FAULTS.

Down selection made:-

1. No lights show, this indicates that the undercarrage is still locked up or electrical fault.

ACTION. 1. Look for change of trim and loss of trim speed.

2. Make a visual check
3. If the up appears to be down check No.13 fuse and if the lights are still out make a buzz test.
4. If the up still remained up check hydraulic pressure (Hand Pump could be tried if time permits)
5. Use emergency air if above tests fail.

## 2 RED LIGHTS SHOWING.

- Indication - neither w/c legs have locked down.

### ACTION.

- Select up and then down again, to test hydraulic system
- If red lights remain on check accumulator pressure
- Use emergency air.

## 3/ 1 RED + 1 GREEN LIGHT.

Indicates starboard (port) w/c locked down Port (std) unlocked. Most probably a faulty micro switch on the Port side.

### ACTION.

- Select up and then down.
- Make a visual check.
- If red light still shows try to build up pressure.
- Make a buzzes test
- Use emergency air.

## 4/ 1 GREEN LIGHT SHOWS.

- Indicates 1 green bulb up.

### ACTION.


- Operate the change-over switch.

### OPERATING TIMES.


40 secs for normal lowering of the w/c.  
During the movement the gauge pressure drops to 220 lbs/ft<sup>2</sup>, builds up to about 300-350 lbs/ft<sup>2</sup>.

and after the undercarriage is fully down  
builds up to 850 W/H<sup>2</sup> to operate the A.G.O.


# B.A. PANEL + RELEASING MECHANISM.



## POWER CIRCUIT



PORT.  
CHARGING.



STBD.  
CHARGING.




WING TIP  
RECOGNITION.

CLEAR  
GREEN  
RED



HEAD OR  
STATION  
LIGHT




OFF

SIGNALLING  
INDEPEND.



ELECTRIC SERVICES CONTROL PANEL.




1. Nav. Lights.

2. Head 4

3/ Upward IDENT.

4/. Downward 4

5/. Wing Formation (REL)



NOTE:- TO SIGNAL WITH

HEAD LIGHT PUT HEADLIGHT SWITCH TO  
"SIGNAL" AND DOWNWARD  
IDENT. "MORSE".

## BOMB GEAR.

### FUSING

HE bomb fusing is controlled from the bomb aimers panel by 2 switches marked, NOSE + TAIL.  
FUSING, SAFE + FUSED.

Incendiaries fuse automatically as they are released from the container and are not controlled from the HE fusing switches. When jettisoning incendiaries safe it is necessary to jettison the container.

### SAFE JETTISON OF A MIXED BOMB LOAD.

1. Check that doors are open.
2. Press the containers jettison switch. (P Panel)
3. Pull the bomb jettison handle " "

### LIVE JETTISON OF A MIXED BOMB LOAD.

4. Doors open.

2. Select Nose + Tail Fusing Switches to Fused.
3. Pull bomb jettison handle.

Mod:- In some aircraft the bomb jettison handle has been replaced by a bomb jettison push button. This does not affect the sequence of jettison.

### RELEASING A BOMB BY HAND.

Bomb releases can be tripped by lifting the trip lever with the aid of a wire hook or in some cases a wooden handle is attached to the trip lever and located under inspection hatch cover. 4,000 lb bombs have a long lever.

fitted to the release unit so that by pulling the handle towards the tail the bomb can be released.

#### RACK JETTISON

- 1) Unlock the 5 pin plug under inspection hatch and disconnect from the socket.
- 2) Turn the steadyng crutch key way anti-clockwise.
- 3) Lift safety catch then knock back the rack release lever.

#### GENERATOR + BATTERY CIRCUIT.

##### BATTERIES.

A capacity of 80 amperes at 24 Volts, is obtained from 4 - 12 Volt 40 ampere batteries connected in series parallel. These batteries assist the generators to operate heavy loads and will maintain essential electrical services in the event of generators failing.

##### BATTERY TEST.

Turn G/F. switch to FLIGHT.

Switch on a load of 8 amps for 5 mins (W.T. motor generator.) Check that the voltmeter reading does not fall below 24 Volts for the test. Turn G/F. switch back to GROUND.

##### DAMAGED BATTERIES.

One battery becoming damaged will cause the undamaged batteries to discharge into

the one damaged and may also reduce the generator voltage to a low figure. Should this occur during flight; turn the G/F switch to GROUND, remove all the battery covers, then disconnect the pair where the one is damaged, insulate the disconnected leads, check that the two serviceable accs are in series, return the G/F switch to FLIGHT.

#### GROUND & FLIGHT Switch.

This switch is the internal battery master switch, being on at flight and off at ground. The switch should always be in the GROUND position when A/c is on the ground, especially when using the trolley acc for starting engines, after engines have been started the switch must be turned to FLIGHT so that A/c circuits can be supplied from internal batteries. The effect of having the switch at FLIGHT with the trolley acc. in use, would be to discharge the batteries into the trolley accs. In some cases the discharge might cause the A/c wiring to burn out.

If the switch is turned to GROUND whilst airborne, the circuits operated from the generators are not affected, unless heavy loads are required in which case the gen. voltage would be reduced to such a low value that circuits may cease to operate.

### GENERATORS.

All the a.c. circuits are supplied from 2 29V. 60 amp generators connected in parallel. The total output obtained are 29V. 120 amps. As engine speed reaches 14-1600 R.P.M. the gen. voltage will rise to 27V. this causes the automatic cut-outs to close which couples the gen. to the battery circuits. the cut-outs remain closed during flight, but will open if the gen. voltage falls below the battery voltage. This prevents the batteries from discharging back through the generators. At approximately 1600-1800 R.P.M. the gen. voltage will have increased to 29V. this causes the carbon pile voltage regulators to come into operation, maintaining the voltage at 29V. with any further increase in Revs.

A current regulator is included in the Voltage Regulator unit, to prevent the load on any one gen. from exceeding 60amps. (2 generators 120amps) The action of this regulator is to reduce the gen. voltage to that of the batteries; when heavy loads are in use, this enables the batteries to assist the generators.

### INDICATORS.

With the G/F switch at FWD and gens. not cut in the two ammeters read 0 (zero) and the voltmeter 24-26 Volts.

With G/F switch at FLIGHT and Gens. cut in both ammeters read charge and voltmeter rises to 29V maximum.

#### INDICATIONS OF FAULTS

1. Voltmeter reading LOW.

One ammeter showing CHARGE, the other showing discharge.

This fault is caused by a 4/5 gen. where the cut-out has failed to open.

#### REMEDY

Remove main fuse of circuit showing discharge.

2. Voltmeter reading over 29V.

One ammeter at charge; the others at discharge  
This is due to a faulty voltage regulator

#### REMEDY

Remove main fuse of circuit showing charge  
and switch off the gen. field switch

3. An Ammeter reading 0 (zero), is usually caused by a blown fuse, but could be due to faulty generator.

NOTE:- The voltmeter reading should remain at 29 Volts during flight, if a low reading is noted (24 Volts) this indicates that batteries are assisting gens. and should be prevented as far as possible by switching off, say unnecessary circuits.

## INSTRUMENTS

### Mk. XII Altimeter:

Consists of 3 exhausted capsules all connected to which is fixed a system of linkage, to a 3 pointers which due to gearing read as follows:

Short Needle - 10,000'

Intermediate " - 1,000' RANGE - 1000 to 35,000'

Long " - 100'

The capsules are in a sealed case which is connected to the static vent.

It is calibrated from a pressure of 1013 millibars. If pressure at sea level increases the pointers can show a reading up to 1,000'.

1 millibar = 30'!

Millibar scale is set everyday to pressure of the day, when this is done the altimeter should read zero! Should the glass be broken the altimeter will read high, due to the pressure in the aircraft being less than atmospheric.

A tolerance of  $\pm 50'$  is allowed

Obtain the pressure of the day from the Met. Office If when the pressure is set on the subsidiary scale, the reading is not in the  $\pm 50'$  tolerance it is due to fatiguing of the capsules and should be put 4/5.

## PROCEDURE FROM TAKE-OFF TO LANDING.

1. Obtain 2 pressures:
  - (a) The pressure at base.
  - (b) " " sea level.
2. While flying over this country the subsidiary scale should be set to (a).
3. When the coast line is reached re-set the scale to (b).
4. Before landing wireless QFE. for the new barometric pressure.

## AIR SPEED INDICATOR.

Pilot head tube which transmits impact and static pressure to the inside of a single capsule. Outside of the capsule is connected to the static vent. All is enclosed in the instrument case, therefore only impact pressure is registered, it is transferred from the capsule to the indicator by means of rotating shaft, quadrant and pinion and registers on indicator the airspeed in M.P.H. The Pilot Head is electrically heated and is controlled by a switch which is on the F.E's panel.

This switch must be put on just prior to take off, and off when landing. Never have the switch on for more than 5 mins when a/c is on the ground.

Range is from 0 - 320 mph.


### RATE OF CLIMB OR DESCENT INDICATOR.

Capsule and mechanism is enclosed in an airtight case, and the capsule is connected to the Static Vent by a calibrated pipe. From this pipe inside the case is taken a lead which has a calibrated restriction. Thus when a/c. is diving, pressure in the capsule becomes greater than the pressure outside due to the restriction, thus a Rate of Descent in Ft./min is registered on the indicator. When the a/c. is climbing, the pressure outside the capsule becomes the greatest, as the air cannot escape very quickly through the restriction, whereas the air escapes immediately from the inside, and a Rate of Climb in Ft/min is registered. The reading given indicates the vertical ascent or descent of the aircraft.

### FAULTS.

If the glass is broken instrument is up. Should a small reading be observed whilst a/c. is on the ground it will be due to fatiguing of the capsule.

Adjustment of  $\pm 1$  small division is allowed ( $\pm 200'$ ) and can be made on a small screw at the right side of the indicator.



A.S.I.

NAV.



INSTRUMENTS.

Mk. III  
ALT.


A.S.I.

BAIMERS  
INSTRUMENTS.

MULTI  
ALT.





STATIC VENTS.



PITOT  
STATIC

Mk XIII  
BOMB  
SIGHT

From MAIN  
CONTROLS COCK  
OR AUTO CONTROLS.



\* 1: A.S.I.

\* 2: ARTIFICIAL HORIZON.

\* 3: CLIMB & DESCENT INDICATOR.

\* 4: ALTIMETER.

\* 5: DIRECTIONAL GYRO.

\* 6: TURN & BANK INDICATOR.

AIR OPERATED.

\* GYROSCOPIC.

## GYROSCOPIC INSTRUMENTS

4. The gyroscope remains perfectly stationary relative to any one position.
5. If a torque is applied to one ring the other ring is precessed.

### DIRECTIONAL INDICATOR.

- Consists of an airtight case, containing a rotor with air buckets around the circumference.
- An inner and an outer ring.
- A PESCO Vacuum Pump draws air from the case at the rate of 4-6 ins of mercury per min. This causes a partial vacuum in the case, and air is drawn in through a filter to a jet which is directed onto the rotor air buckets. This jet drives the rotor at 10,000 RPM, it taking about 5 mins for the rotor to gain top speed.
- At this speed centrifugal force acts upon the rotor and keeps it perfectly stationary.
- A cage knob is fitted which when pushed in, by means of a cage arm locks the rotor upright, and a pinion engages into a toothed ring to lock the compass chart. Turn the knob to set chart as required.
- When starting always have the button pushed in, until the engine has run for 5 min. After 5 mins. knob can be pulled out and rotor will remain stationary due to centrifugal force.

### BLIND TAKE-OFF.

Set indicator with knot to zero.

Pull out the knot.

By keeping zero in centre of instrument  
a straight take-off will be made.

### WHEN IN FIGHT

Set the compass chart with the caging  
knob, to read the same as the magnetic  
compass.

Re-set every 15 minutes as by that time  
error of 2-3 mins. will have crept in.

### BLIND LANDING.

Set indicator with knot to zero.

Pull out knot.

By keeping zero in centre of instrument  
a good straight landing will be made.

Turns are always made on the directional  
indicator, as magnetic compass reads incorrectly  
on turns, due to

1. Liquid Swirl.
2. Centrifugal Force.
3. Acceleration Force.

## TURN AND BANK INDICATOR.

Consists of an light case, rotor and inner ring, the casing itself acting as an outer ring. It controls the lower pointers which indicates the rate of turn of the aircraft. The movement of the air applies torque to the instrument casing (outer ring) which precesses the inner ring, so causing the rate of turn to be indicated.

There are 4 rates of turn:-


1,  $170^\circ/\text{min.}$

2,  $360^\circ/\text{min.}$

3,  $660^\circ/\text{min.}$

4,  $1080^\circ/\text{min.}$

The movement of the inner ring is controlled by a spring. Inner ring is pivoted at front and rear of the instrument.



The top pointer is connected to a pendulum, and registers the degrees of over or under bank of a turn.


When both pointers are on left of dial, it indicates overbanking on left turn.

When top pointer is over to the right and bottom pointer to the left, it indicates underbanking on right turn.

Therefore, if both pointers were to right it shows overbanking on right turn.

When top pointer is to left and bottom to right it indicates underbanking on right turn.

The top pointer is not controlled gyroscopically but merely by action of the pendulum. Bottom of pendulum and top of pointer are always in the same direction.



### ARTIFICIAL HORIZON

Rotor is enclosed in Inner Ring, which is pivoted in sides of outer ring. The outer ring is pivoted fore and aft.

Air to drive gyroscope comes in the filter at the seat, through the outer ring, through the inner ring pivot and passes round inner ring's slots and via jets to drive the rotor. Air comes out through 4 bisected slots to Perco Pump. When gyroscope is erect air comes out of each hole equally, but if not erect air comes out unequally and so applies a torque to ring, in opposition to centrifugal force on Pendulous Vanes. So correcting rotor for centrifugal forces.

The Pendulous Vanes are fitted over the bisected slots to keep the air outlet equal and so keep the gyro rotor upright.

Plane above horizon climbing

" below " diving

Port wing plane above " - Port wing high  
" " " " low

In turns the Pendulous Vanes cause a slight incorrect reading due to centrifugal force.

## AUTO CONTROLS.

### POSITION OF COMPONENTS.

RAE COMPRESSOR: Rear of "B" Bank Port Inlet.

OIL COOLER: Rear of "A" bank Port Inlet.

OIL RESERVOIR & SEPARATOR: Auxiliary Panel, Port Inlet.

CHEMICAL AIR DRIER: Along Port side navigators table.

TEST COCK: Just behind Pilot Port Side.

MAIN CONTROL COCK: CLUTCH LEVER, MAIN SWITCH, ATTITUDE CONTROL  
All on Port side of Pilot.


STEERING LEVER: On Pilots panel in front of control column.

STEERING CONTROL, RUDDER & ELEVATOR PLATE, AILERON PLATE, TURN  
REGULATOR: Port Side Bomb Aimers Position


3 SERVO MOTORS: - In front of Pilot.

AIR THROTTLE - Port side of Bomb Aimers Position.

DIAGRAMMATIC LAYOUT OF Mk.IV AUTO CONTROLS.



## LAYOUT OF AUTO CONTROL. (Rudder)



INLET LAP -  $1\frac{1}{2}$  THOU.

EXHAUST " -  $1\frac{1}{2}$  "

## DAILY INSPECTIONS.

4. Put the clutch lever in, and move the controls in all directions to make certain clutches are engaged.
2. Check the oil level in the oil reservoir and separator.
3. Check the silica gel in the C.A.D. This is changed every 10 engine hrs or every operational trips (white to brown or blue to pink).
4. Start Post Tunes Engine and put M.C.C. to spin.
  - 5. Check air pressure. (60 lbs/ft<sup>2</sup>)
  - 6. See that unit covers are secure.
  - 6. See that attitude control is at zero. Steering lever is at central, and main switch off.
  - 7. Centralise the controls and put the M.C.C. to the in position. Control column will now move forward. Check that all controls are locked. (Check in clutches)
  - 8. M.C.C. out.

## BEFORE TAKE-OFF.

1. Clutches in
2. M.C.C. out.

## IN THE AIR.

4. Put M.C.C. to spin for 5 minutes.
2. Climb to 2,000 ft or above and level out.
3. See that attitude control is at zero, steering

levers central and main switch off.

Trim aircraft to fly hands and feet off.

5. Put M.C.C. in.

6. To climb or dive operate attitude control

7. To turn operate steering lever after putting main switch on. After turn centralize lever and switch off.

8. If combined air pressure gauge is reading tail or nose heavy, put the M.C.C. to spin return the a/c. and put it back in again.

9. To take evasive actions put M.C.C. to spin or out.

#### BEFORE LANDINGS.

1. Put M.C.C. out.

2. Clutches out.

N.B. Clutches are only withdrawn prior to landing and in cases of emergency. e.g. damaged servo motors.

#### DISTANT READING COMPASS.

For Take off, landing and Taxying the main switch must be on; and the normal setting switch setting. After 5 mins the normal setting switch can be placed to normal.

N.B. The main switch is not to be put on until after the engines have been started.

## AIRFRAMES 3RD WEEK.

### FLIGHT ENGINEERS PRE-FLIGHT CHECKS.

#### EXTERNAL CHECKS.

1. General aspect of aircraft (ie. oleo leg extension). 4-7 inches
2. Chocks under wheels.
3. Check tyres for pressure, cuts, oil sootage and especially creep, brake pads,
4. Jopy struts removed
5. Check for coolant leaks and any leakage from emergency air valve, oleo legs and ac jacks.
6. Inspect up latch locks for cleanliness and up members generally for damage. Check Props.
7. See that covers are removed from the cable cutters and pilot head. (fuel jettison flap)
8. Check the hinged leading edge for security also all cowlings and panels.
9. General <sup>check for</sup> damage to nacelles, ailerons, etc., paying particular attention to attachment screws of panels under fuel tanks.
10. Examine fuselage for damage.
11. Remove static vent plugs.
12. Check external first aid and dinghy releases.
13. General check for damage to fins, rudders, elevators and tailplane.
14. Inspect mast and tailwheel and oleo leg. (4" approx)
15. Check that cock on emergency air for bomb doors is open.

### INTERNAL CHECKS

(use inside turret)

1. Remove bubbles from rear turret cut-off valve.
2. Check portable oxygen bottle and fire ext. extinguisher at rear of draught proof doors.
3. See that fuel and oil dipsticks, first aid kit and axe are correctly stowed.
4. Check oxygen bottle and fire ext. on starboard side near mid upper gunner.
5. Remove bubbles from mid upper turret cut-off valve.

Check All loose equipment.

1. Security of bomb slip covers.
2. Check pyrotechnics for security. (flame floats etc.)
3. Check security of rear ditching exit.
4. See that oxygen bottle, control locking gear and axe are correctly stowed.
5. Check w/app portable oxygen bottle, and fire ext. on starboard side near front spar.
6. Check pressure of nitrogen system. (1800 t200)
7. Check mid-ditching exit.
8. Turn on oxygen supply cock.
9. Turn G/F switch to FIGHT.
10. Check emergency air pressure. 1200 Normal, 800 minimum.
11. Check that accumulators are connected properly.
12. Check initial pressure of hydraulic accumulator.
13. Check level of fluid in hydraulic reservoir.
14. See that balance cock is off, checking first of all for operation.

FRONT SPAR

1520. See that all negative switches are on.
1621. Check oxygen bottle and fire extinguisher at  
navigator's position. Cabin Heating OFF.
1722. Test operation of a/c. horn.
1823. Check Pilots oxygen bottle, fire ext, and a/c.
1924. Test operation of brakes and pneumatic auxiliaries.
2025. Check controls and trimmers for full, free,  
and instinctive movement. Auto-Control Clutches IN.
2126. Check forward ditching exit.
2227. Check fuel contents, and test booster  
pumps by ammeter, leaving fuel contents switch  
on. Pressure Test on Booster Pumps.
2328. Check security of bomb-aimer's parachute  
exit.
2429. Check oxygen bottle and fire ext. and  
remove bobbin from front turret.
2530. Check de-icing tank.

### STARTING PROCEDURE.

- B. - Brake Pressure, 150 lbs./sq" minimum.
- I. - I.C.O.'s to I.C.O. position.
- G. - G/F switch to GROUND.
- B. - Boost Cut-Out Levers UP.
- U. - Undercarriage and Flap indicators ON.
- S. - Supercharger "M" gear.
- T. - Throttles  $\frac{3}{4}$ " OPEN.
- U. - Undercarriage lever locked DOWN. Bomb Doors CLOSED. Flaps NEUTRAL.
- P. - Props. MAX. R.P.M.
- A. - Air Intakes COLD. Fuel Jettison NORMAL.
- M. - Master Fuel Cocks "OFF"
- P. - Pumps on No 2 tanks. Select No 2.
- S. - Select Master Cock for engine to be started.
- I. - Ignition Booster Coil "ON."
- P. - Prime Engine.
- S. - Starter Button "PRESSED."
- I. - I.C.O. to engine RUNNING. (Back to I.C.O. if engine fails to pick up)      I.C.O. = IDLE CUT OFF

### AFTER STARTING.

- 1. G/F Switch to FLIGHT
- 2. Booster Coil OFF
- 3. Check engine pressures and temperatures.
- 4. Test operation of flaps and bomb doors.
- 5. Check Change-over Vacuum Pump Cock.
- 6. Carry out Running Up Checks.

BEFORE TAXYING.

- B. D.R. Compass on and to SETTING.
- U. Undercarriage lights Change overs switch - check for correct functioning.
- M. Mixes box to 1/6 position
- B. Brake Pressure. 150 lbs/ft minimum.
- B. Bomb Doors Closed
- O. Oxygen checked with rest of the crew.
- A. Altimeter set allowing no lag.
- T. T.R. 1196. Ground Test.
- M. Magneto switches locked on.
- A. Auto Controls main switch OFF
- N. Navigation lights as required.

DRILL OF VITAL ACTIONS.

- A. Auto Control Clutch IN.
- A. Auto Controls OUT.
- A. Air intakes COLD.
- F. Friction nut tight.
- F. Flaps 15° light 25° Heavy.
- F. Fuel No2 tanks, All main Boostes Pumps ON  
Master Cocks ON
- S. Supercharges 'M' gear.
- T. Trimmers set by Pilot.
- R. Radiator Flaps, outboard OPEN. inboard AUTO.
- B. Boost Cut-Out lever as required.
- P. Pitot Head Heaters ON.
- P. Pneumatic Pressure 150 lbs/ft
- P. Progs maximum R.P.M.

## IMMEDIATELY BEFORE TAKE-OFF.

- F. Final Check on engine temperatures & pressures.
- A. All unnecessary lights OFF.
- D. Directional gyro set to zero and uncaged.
- E. Engines Cleared

## PIROTECHNICS.

### RECOGNITION OF PHOTO-FLASH.

Cylindrical in shape, body painted black, tail fins painted red, half inch red band around nose, and the word FLASH in white.

#### PURPOSE.

Illumination of target for the purpose of night photography.

#### SETTING & LAUNCHING.

No. 848 fuse screws into the nose, and the applicable delay capsule is inserted.

Place photo-flash in flare-chute tail first and suspended by means of a lug provided. Attach static line to arming vane cover.

Remove safety pin.

Launch by tripping release mechanism, either electrically or manually.

#### PRECAUTIONS.

1. Ensure that the necessary capsule is in position.
2. If photoflash is not used replace safety pin.
3. Disconnect static line.

# RECOGNITION OF PYROTECHNICS.



Purpose is for navigational use by night at sea, air sea rescue, emergency flare path for ditching.

SETTING + LAUNCHING: (1) Pierce tail sealing disc with punch & remove Punch (2) Pierce safety pin & protecting nose cap (3) Launch tail first. Flame float must be launched if tail sealing disc is pierced. Lasts 6 mins.



Purpose: (1) Navigational aid by day at sea (2) Sea Rescue Work.

SETTING + LAUNCHING: (1) Remove Safety Pin & launch tail first.

If it is not used the pin can be replaced and the float is safe. Lasts for 6 mins.

## FLAME FLOAT.

MK. II

## SMOKE FLOAT.

MK. IV




USED TO MARK POSITIONS AT SEA.  
TO PROVIDE TARGET FOR BOMBING AT SEA.

### SETTING + LAUNCHING.

- (1) Remove transit pin.
  - (2) Launch tail first.
- Pin can be replaced if not used.
- Break on impact with sea and spreads over the sea a layer of aluminium.

SEA MARKER (ALUMINIUM)  
MK. II



Cylindrical in shape and telescopic, extend fully and launch nose first. On impact it is contracted and a set of knives at the top cut through a bag containing aluminium and spreads it over the sea.

SEA MARKER (ALUMINIUM)  
MK. IV

### RECO-FLAKE.

Similar in shape and size to photo flash.  
Painted black with half-inch red band  
round nose. Fins do not protrude.

### PURPOSE.

For the illumination of an area for the  
purpose of identification at night.

Launched the same way as photo flash.  
Fuse 42 used for reco flare.

### SIGNAL CARTRIDGES.

#### 4. SINGLE STAR - ONE COLOUR.


COLOURS USED: Red (7 secs) Green (7 secs).  
Ruby (8 secs) Yellow (8 secs).



NOTE: As the red cartridge is used for a distress signal, its rimmed base is milled to enable it to be easily distinguished in the dark.

#### 4. SINGLE STAR - CHANGING COLOUR.

COMBINATIONS: Yellow - Green; (5 and 4 seconds).



White - green; (3 and 8 secs).

Colours are also printed on base.

#### 3. DOUBLE STAR:

COMBINATIONS: Green - Green; Green - Red; Red - Red;  
Yellow - Red; Yellow - Yellow; Green - Yellow.



### ILLUMINATION CARTRIDGE.


This is used chiefly as a preliminary to the rec. flare in order to obtain a glimpse of the country over which the ap. is flying. It is longer than the signal cartridge and burns for approx. 10 secs.

NOTE:- The cartridge should not be fired at heights of less than 2,500 ft over friendly territory unless in emergency, as it is liable to set fire to objects on the ground.

### BROWN & WHITE Smoke PUFFS:

Are mainly used by rec. sections in order to ascertain the speed and direction of the wind. Identified by 4 Coloured serpentine symbol, painted on the side of the cartridge and the usual label on the top.

TRAVELLING FORM 700A.

AIRCRAFT.			AERO ENGINES.			
TYPE.	MARK.	No.	TYPE.	MARK.	No.	
LANCASTER	MK. III	L 2714	MERLIN	MK. XXXVIII		
FUEL OCTANE	100		"	"	"	
OIL	D.T.O. 422/18		"	"	"	
COOLANT	70/80		"	"	"	
PERIODICITY OF MINOR INSPECTION 40 HRS. TYPE OF NEXT INSPECTION DUE FOR						
FLYING HRS. PROGRESS TO NEXT INSPECTION	→ 					40


DAILY INSPECTION CERTIFICATE.

DATE	SIGNATURES				TESTIMONY				TIME	SIGNATURE OF NCO. I/C
	AIRMAN	AERO. ENGINE RIDING R.C.	AERO. S.P. DRIV. S.D.	INST.	ELEC. WHEELS	ARMED EQUIPMENT	EXTRAP.			
25/3/44	F/G. F/G.	F/G. F/G.	F/G. F/G.	F/G.	W/D.R W/D.R	NAV FBOMBS	P/G.L. H-60			F-ENR.

FLYING TIMES.

DATE	UP	DOWN	IN AIR		FUEL RATE A.I.C. GAL. IN A.I.C.	TOTAL FUEL IN AIR GAL.	TOTAL OIL IN AIR GAL.	TOTAL COOLANT IN AIR GAL.	STATE	SIGNATURE OF AIRMAN RESPONSIBLE	SIG. OF PILOT
			HOURS	MINES.							
25/3/44	1600	1600	1.	0	160.	16.00			FULL	F/LIN.	Pilot.

## OLEO STRUTS.



These tables are to give a check against the amount of oil in oleo leg. With the weight of a/c on the oleo correct amount of oil will give a range of air pressure and an extension of oleo in inches.

U/C OLEOS FULLY EXTENDED - 995 lb/in  
TAIL " " - - 650 - -

a/c jacked up.

DIMENSIONS AT X	MIN	MAX.
4.92	650	700
4.5	690	745
4.0	750	810
3.5	820	885
3.0	905	975
2.5	1005	1080
2.0	1130	1220
1.5	1295	1395
1.0	1515	1625
.5	1820	1970
.32	1920	2200

TABLE OF PRESSURES.

AUTO-CUT-OUT	-	750 - 350	lbs/in <sup>2</sup>	"
CUTS IN	-	220	"	"
PNEUMATIC	-	270 - 320	"	"
RELIEF VALVE	-	20% of above.	"	"
NITROGEN	-	1800 ± 200	"	"
OXYGEN	-	1800	"	"

MAIN TYRES: 43 " "

TAIL TYRE 34 " "

MAIN OLEOS. 995 " "

TAIL OLEO 650 " "

} a/c jacked up.

EMERGENCY AIR: 1200 " "

EXPANSION VALVES: 1200 " "

CHECKING OIL LEVEL IN OLEO LEGS.

- 1. Allow leg to support aircraft.
- 2. Attach Turner Adaptor to inflation valve.
- 3. Operate the adaptor to release air pressure and allow unit to compress fully.

If at the final stage of compression a spray of oil and air is blown off the oil level is correct.

If only oil is blown off it means there is too much oil in.

If only air is blown off there is too little oil.

## FILLING OLEO LEG WITH OIL.

1. Jack up aircraft
2. Connect 2 way pump to inflation valve.
3. Pump in oil until pressure gauge reads a rapid rise in pressure, not exceeding 3,325.  
lbs/ft<sup>2</sup> main oleos, 1,200 lbs/ft<sup>2</sup> on the tail oleo unit.
4. Allow unit to support aircraft.
5. Release Pressure Gradually.
6. Allowing struts to compress fully, to remove surplus oil.

## Final Check.

Pump in 50 lbs/ft<sup>2</sup> air pressure,

Allow legs to compress, as air an oil mist should blow out.

Jack up w/c and pump in 995~~0~~ lbs/ft<sup>2</sup> air press  
for main oleo, 650 lbs/ft<sup>2</sup> tail oleo.

## N.B.

Always remove dust cap before commencing.  
REPLACE " after completion.

## IDENTIFICATION. OF PIPELINES.

HYDRAULICS - White.

Undercarriage - Red with white background.

Hot & Cold Air Intake - Brown - " "

Bomb Doors - Yellow - " "

Flaps - Green - " "

Fuel Jettison - Black - " "

Emergency - Yellow Purple Yellow - "

Pneumatics - Yellow.

Fuel - Red

Oxygen - White-Blue.

Fire Ext. - White Red.

Nitrogen - White Red White.

Anti-icing - Brown White Brown

Auto Controls - Browns.

### TURRETS:

Front - White Yellow White

Mid-Uppers - " Blue "

" Under - " Green "

Rear - " Red "

Vacuum System - White Black

Engine Starting - Green.

Coolant - Blue.

Oil - Black

## BLEEDING OF HYDRAULIC SYSTEM.

### AFTER USE OF EMERGENCY AIR.

1. Ensure that the air control has been returned to OFF position and up lever LOCKED DOWN.
2. Aircraft jacked up.
3. Slacken the bleedet screws in the top of the 4 undercarriage jacks (down side).
4. Fill up reservoir.
5. Establish the cause of hydraulic failure, necessitating the use of emergency air and rectify it.
6. Connect ground test rig to ground test couplings, and start up the rig at its slowest speed.
7. When a column of oil free of all air, emerges from the open bleedet plugs, tighten and relock plugs, and build up to cut-out pressure.  
Same procedure is carried out for FLAPS.  
Fully raise and lower the up and flaps several times to remove any air.

N.B.

Should oil issue from the vent into the nacelle, give the emergency air valve a sharp tap with a ride hammer.

Finally lower up and re-fill air bottle to 1200lb and top up reservoir.

## FIRST AID OUTFIT FOR AIRCRAFT.

1. Ampoules, Iodine. 30 Minims each.  
for minor wounds. (3)
2. Ampoules, Morphia (syringe). in tin box, with labels.  
FOR SEVERE PAIN: Use the contents of one ampoule.  
Remove Hood; Press Stylet (blue in needle) down  
until it punctures top of capsule. Remove Stylet.  
Hold Syringe needle upwards and press capsule  
until a bead of moisture appears at top  
of needle. (2)  
Pinch up portion of skin of arm or leg.  
Then insert needle beneath skin obliquely; empty  
capsule by squeezing. Give contents of one  
ampoule only. Complete a label and attach  
it to patient.
3. Anti-burn Remedy: (in 4oz tubes).  
For burns, spread over burn and apply dressing.  
Don't use it on eyes or eyelids. (1)
4. Bandages (TRIANGULAR) (2)  
To be used as a sling or bandage.
5. Shell Dressings. (2)  
To be used as directed on outer cover.
6. Adhesive Plaster 1-inch in ten.
7. Scissors, straight beonet, 7" for cutting clothing.
8. St. John Tourniquet. (2)  
When an artery of a limb is cut and blood gushes  
out and a firm dressing will not control bleeding, a  
tourniquet should be applied above wound

with block pressing on artery. The stick should then be twisted round until bleeding stops.

Secure end of stick by tying attached cord to end of D Ring on buckle.

At the end of each 20 minute period after application, stick should be gently untwisted to see if bleeding has stopped, if not re-apply.

- If stopped apply an ordinary dressing.
- 91 Satchel to contain above items.

PICKETING POINTS.

One outboard of each inner engine, at leading edge.  
One just inboard of detachable wing tips on each side, at leading edge.

An eyebolt screws in to the longerons at each side approx at formers 22.

PICKETING.

Always stand aircraft on firm ground.  
Facing the wind.

Tie through picketing points to ground weights.

MERLIN 22-24-28-38 ENGINES GENERAL.

COOLANT SYSTEM.

Coolant is taken from the header tank to the thermostat, if the temp is under 85° centigrade, all the coolant is by-passed, and goes straight to the pump. If over 85°C. but under 105°C. then part is by-passed and remainder goes through the radiator.

- 105°C. all the coolant goes through the radiator to the Pump. From the Pump it goes to A & D. Blocks.

A. BLOCK STAR SIDE.

The coolant passes through A Block to an external coolant rail which carries a part of it back to header tank, the remainder is taken by an external pipe at the rear to the carburettor jacket (Merlin XXII), and then is fed back to inlet side of coolant pump. (On Merlin XXVII Carb union is blanked off.)

B. BLOCK PORT SIDE.

As for A Block except on the two inner engines the external pipe carries the coolant to the cabin heaters and then back to the inlet side of the pump. On the two outer engines rear of coolant rail is blanked off. The pressure is maintained and controlled by the thermostatic header tank relief valve, which has 4 main functions

- 4. Relieves the system of any air locks after starting up. (Relieves at 30lb/in² pressure) (allows atmospheric pressure in at -2' Hg approx 138°C. below atmospheric).

2. Keeps a constant pressure on coolant increasing boiling point.
3. Prevents loss of coolant, due to venting or banking.
4. Compensates for depression in the tank as the coolant temp decreases.

The minimum temperature is controlled by the thermostat, the max, by the rad. shutters. A thermostatically operated switch operates the rad shutters, opens them at 105°C. as the coolant warms up, and closes them at 99°C as the coolant begins to cool down. A master switch or override switch is fitted so that the radiator shutters may be opened or closed at will by the F.F. The shutters must always be open for ground running and taxying.

#### FAULTS.

#### SYMPTOMS OF FAILURE.

#### THERMOSTAT.

1. Long periods of warming up.
2. Tendency for temperature to fluctuate with altitude.
3. Tendency for thermostat to maintain low temps.

#### CHECKS. NOTE.

Thermostat with yellow band must only be used on pressurised 70/30 systems.

AUXILIARIES DRIVEN BY ENGINE.

COMPONENTS.	OPERATION	WHERE FITTED.
<u>PORT OUTER.</u>		
A.C. ALTERNATOR GENERATOR TURRET PUMP.	WIRELESS EFF ETC "GEE" FOR REAR TURRET.	P.S. OF CRANKCASE "A" BANK.
<u>PORT INNER.</u>		
DC GENERATOR.	MAIN ELECTRICAL SERVICES.	P/S. OF CRANKCASE.
DOWTY HYDRAULIC PUMP.	" HYDRAULIC "	BASE OF SUMP
PESCO PUMP NO.1.	INSTRUMENTS.	STBD. SIDE DUAL DRIVE.
R.A.E. COMPRESSOR.	AUTO CONTROLS. (GEORGE ETC)	"B" BANK.
TURRET PUMP	MID UNDER TURRET.	"A" BANK.
<u>STBD. INNER.</u>		
DC GENERATOR.	MAIN ELECTRICAL SERVICES.	P.S. OF CRANKCASE.
DOWTY HYDRAULIC PUMP	" HYDRAULIC "	BASE OF SUMP
PESCO PUMP NO.2.	INSTRUMENTS. B.SIGHT.	STBD. SIDE DUAL DRIVE.
HEYWARD COMPRESSOR	PNEUMATICS	"A" BANK.
TURRET PUMP	FRONT TURRET	"A" BANK.
<u>STBD. OUTER.</u>		
TURRET PUMP	MID-UPPER TURRET	"A" BANK.
GENERATOR ALTERNATOR.	NEW DEVICE. (RADIO) H2S.	P.S. OF CRANKCASE.
COMMON TO ALL ENGINES. C.S.U. P.S. DUAL DRIVE.		
OIL USED -	D.T.D. H72B.	
L.A.F.U.		

## ENGINE LIMITATIONS.

CONDITIONS	BOOST	R.P.M.	COOLANT	OIL	LIMITS.
MAX TAKE-OFF M	+14	3,000	125°	-	5 MIN. OR 6,000 ft.
MAX CLIMB. M	+9	2,850	125°C	90°C	1 HOUR
" " S	+9	2,850	125°C	90°C	1 HOUR.
MAX CONTINUOUS M	+7	2,650	105°C	90°C	
" " S	+7	2,650	"	"	
COMBAT M	+14	3,000	125°C	105°C	5 MINUTES.
" " S	+16	3,000	"	"	"

+14 in "M" and +16 in "S" are obtained by pulling cut-out which should only be necessary in combat  
 Minimum oil pressure 3045 lbs/ft.  
 Normal " " " 4500-80 lbf/ft

## FULL THROTTLE HEIGHTS.

R.P.M.	BOOST	ALTITUDE. M.	S.	REMARKS.
1800	+4	3,000	-	FULL THROTTLE HEIGHT.
2650	+4	14,000	20,000	" " "
2650	+7	9,000	16,000	" " "
2850	+9	10,000	17,500	RATED ALTITUDE.
3000	+9	12,250	20,000	MAX POWER ALTITUDE.
3000	+14	6,000	-	WITH CUT-OUT PULLED
3000	+16	-	13,000	" " "
3000	F.O.B. +18	-	-	FALLS OFF IMMEDIATELY ON LEAVING GROUND.

3,000' +18 can be got with a Merlin 24

## LUBRICATION SYSTEM

Oil flows from tank through filter to C.R.V. This regulates pressure to between 45 and 80 lb/ft. Two main pressure connections are taken from the C.R.V. as well as temperature and pressure. One connection leads oil through a duct in the crank-case wall to lubricate the shaft bearings, and the other conveys oil, via an external pipe to the prop. This pipe divides just behind the reduction gear casing, one branch taking oil direct to stbd banjo union & the front of prop piston. The second branch takes oil to the C.S.U. booster pump which boosts up pressure to approx. 200 lb/ft; then delivers it through an external pipe, to the similar banjo union on the port side of reduction gear casing and so down to rear of prop piston. A small pipe conveys oil direct from pressure pump to the fuel pump drive, and on the starboard inner engine only this pipe continues upwards to lubricate the Heywood Compressor. Any surplus from fuel pump drive is drained to atmosphere, while that from the compressor is drained to the wheelcase.

## LOW PRESSURE SYSTEM

2 low pressure connections are made from the C.R.V. one leading forward to supply the reduction gear jets while the other leads rearwards to a junction, from which branch lines are taken to lubricate, camshafts, generator drive, splash gears and rear discharge leg.

## SCAVENGE SYSTEM.

Consists of 2 scavenge pumps, housed in the rear sump. Each pump draining its own sump through a separate filter. Oil from the pumps is delivered through a common outlet, in std side of rear sump, through an external pipe to the supercharger servo unit. From here the oil passes to the throttle butterflies (where a 30 lbs relief valve is fitted) and then on to Clarkes viscosity valve, which sends it direct to the tank if cold, or through the cooler, and then to the tank if hot.

## Piston, BUTTERFLY & THROTTLE LEVER POSITIONS.

1. 	2. 	3. 	4. 
SLOW RUNNING.	RATED BOOST. (S.L.) 2850 +9	TAKE-OFF. 3,000. +14.	


5. 	6. 	7. 	8. 
3000 +14 CUT-OUT PULLED.	2850 +9, 10,000' (APPROX) OR ANY FULL THROTTLE HEIGHT	2650 +4 SEA LEVEL	

9. 	10. 	11. 	12. 
*	2650 +4 10,000' (APPROX)	2650 +4 12,000' (APPROX)	*

13. 	14. 	15. 	16. 
S	2650 +4 20,000	2850 +6. 23,000' 13,000	S

Note that relay piston is fully forward to maintain selected boost, Throttle lever is slowly moved towards gate as altitude increases.

COOLANT SYSTEM.




MERLIN XX. DR BELOW HHS COOLANT RAILS

" XXII " ABOVE " ONE ELBOW LEADING OUT OF EACH BANK.


MINIMUM TEMP.- 60°C.

MAXIMUM. " 135°C.

# LUBRICATION SYSTEM.



# SCAVENGE SYSTEM.



DTD 472 BX.

Low Pressure. 6-10 lb/in<sup>2</sup>


Main Pressure. 45 lb/in<sup>2</sup>

High Pressure.

Scavenge.

Min. Oil Press. - 30 lb/in<sup>2</sup>

# R.R. BOOST REGULATOR.



## R.R. BOOST REGULATOR.

THE OBJECTS OF THE R.R. ARE:

1. To prevent the pilot's lever giving and excessive boost to the engine.
2. To ensure that a definite response is obtained from the engine for any change in throttle lever position.
3. To prevent alteration of the boost selected by any given throttle lever position, due to changing altitude, barometer, &c. a/c. altitude.
4. Similarly to maintain the boost within the range of control available in spite of engine R.P.M. alterations, by the R.P.M. lever.

It is a control on the position of the throttle butterfly, actuated by the tendency for change in boost pressure from the valve, selected from the throttle lever. The normal readiness position of the piston valve closes both ports to the front and rear of the relay piston, which will be situated at some position depending on altitude and the cockpit throttle lever. Tendency for boost change is felt by the aneroid which expands or compresses slightly so that the piston valve admits pressure to one or the other sides of the relay piston. This moves, and the link swings about the central pivot (A) to which the (assumed) stationary pilot's lever is connected, hence the ~~butterfly~~

butterfly throttles are adjusted to prevent boost from changing. The swinging link which uses the central pivot (A) when relay piston compensation takes place, and the lower pivot (C) when a fresh position of the throttle lever is selected, is identical in effect to the more complicated looking differential on the engine control shaft. Note now that any movement of the throttle lever (from 2lbs boost upwards) bodily displaces the aneroid and piston valve assembly by a cam, and the readiness position will not be restored until a new value of boost has produced the necessary alteration to the aneroid bellows length, hence the boost changes are progressive in sympathy with the throttle lever.

#### Maximum Gains.

At the gate, on the ground, the relay piston is nearly at its full rearward position (R hand end of cylinder) leaving a bit in hand, to cope with air intake ramming effect on moving forward airborne. It gets there by the following sequence of events:- the throttle lever pushed forward to the gate finds no mechanical reason against the throttle opening wide to start with. The piston valve assembly also is pushed down by cam pressure. The rising boost compresses the aneroid, lifting the valve until it starts passing boost pressure to the forward end, (left hand) of the relay piston,

and at the end of its travel this has limited the butterflies to the position giving rated (max climbing) boost. Not surprisingly, this amount of (boost) opening is nowhere near the fully open butterfly position, which would give a boost about three times the value of the allowable rated boost.

On the climb, the effect of the steady decrease in atmospheric pressure at the intake is counteracted by the slow movement forward of the relay piston opening the butterflies to maintain boost.

#### LOWER BOOSTS.

Only at rated boost and International R.P.M will the relay piston have its full travel available to hold the boost at rated altitude. At partial throttle lever position or a reduced R.P.M, boost will be maintained only to some lower altitude. If at partial throttle, manual opening must then be used to prevent boost falling on further climb past this height. The mechanical reason is that the relay piston is not fully to the rear, and reaches its forward stop earliest on climb, with the butterflies still short of full open.

#### TAKE-OFF BEHAVIOR

Going through the gate manually opens the butterflies to a rather wider position. But, as the relay piston is already fully to the rear at the gate, it cannot prevent the boost rising to the 1.0 value.

It is thus not in control and the boost will decrease during the 1,000 ft permitted for T.O. conditions.

#### Booster Control Cut-Out.

This is used in emergency only, and also for take-off and its effect is to supply a false sample of boost pressure to the aneroid chamber by ducts. It is thus tricked into controlling at a higher boost, which can only be maintained up to lower heights, as the butterflies are wider open and the relay piston already further forward than at the normal controlling condition.

When the boost obtained is less than that selected the relay piston is fully forward.

The higher the boost and fixed R.P.M. the lower the full throttle height. The lower the boost and fixed R.P.M. the higher the full throttle height.

E.G. 2650 +7 - 9,000' in M. gear.

2650 +4 - 14,000' - - -

The higher R.P.M. for a given boost the higher the full throttle height, the lower R.P.M. for the same boost the lower the full throttle height.

E.G. 2650 +4 - 14,000' in M. gear.

1800 +4 - 3,000 - - -

If the throttle lever is at the gate and the boost below +9 then the butterfly is wide open and the sp. is at full throttle height.

If the throttle lever is at the gate and the boost is +9 it is impossible to tell whether the aircraft has reached rated altitude or not.

If the throttle lever is not at the gate and the boost commences to drop, then the a/c has not reached its full throttle height as it is an impossibility for the butterflies to be opened fully with the throttle lever not at the gate, manual control is necessary to open the butterfly.

#### FAULTS OF R.R. BOOST REGULATOR.

##### ADJUSTMENTS.

Rated boost, adjusted by a screw on top of regulator, quarter of a turn equals  $\frac{1}{2}$  lb, screw in to increase, out to decrease.

##### Excessively high boost

1. Failure of aneroid.

2. Leak on dome nut on regulator.

##### Low Boost.

Usually caused by a leak between engine and gauge or on gauge itself.

##### SURGING BOOST.

This is noticed when boost fluctuates with a more or less rhythmic period.

1. Sluggish, sticky or too slack relay piston.

2. Sticking piston valve.

3. Excessively light or slack control rods, particularly the rod from the relay piston to the

differential gear lever.

4. Congealed oil in the differential.

#### LUBRICATION


All parts to be lubricated with a mixture of  $\frac{2}{3}$  engine oil, and  $\frac{1}{3}$  anti-freeze oil. To lubricate shaft of relay piston remove triangular plate and put in 1 teaspoonful (35c) of oil.

Also lubricate piston valve and differential.

#### ATMOSPHERIC CHANGE-OVER COCK CLOSED.

As the difference between pressure and intake side of supercharger is practically nil at low R.P.M. a change-over cock is fitted, being controlled by the Pilot's throttle lever admitting atmospheric pressure in lieu of pressure from the off into the piston valve, this atmospheric pressure is in operation during low revs until approx. 2 lbs boost. When the valve returns supercharged pressure to the operating side of the boost regulator.

## MERLIN 2 SPEED SUPERCHARGER.




Consists of 3 multi-plate slipping clutches  
2-driving 5" gears - 1-driving 7½" gear. Clutches  
are engaged by small flyweights which,  
when flung out under centrifugal force,  
press the clutch plates together and cause  
the clutch to drive. To allow 1 gear to be  
disengaged while the others are engaged each  
clutch is provided with a ball race, operated  
by a forked arm on a cam, the cam being  
mounted on a small camshaft, operated by a  
servo piston. When 7½" gear is engaged its ball-  
race will be clear of the flyweights allowing  
them to fly outwards, so causing the gear  
to drive, while 5" gear ballrace will be  
pressing against the tips of the flyweight  
preventing them from being flung outwards, so allowing  
5" gear to slip. (When 5" gear is engaged the procedure  
is reversed).

### FAULTS.

1. Total loss of oil, S.P. stays in gear selected.
2. Manual control breaks S.P. stays in gear selected.
3. The pneumatics fail, springloaded jacks return S.P. to 7½"
4. Slipping clutch. Low boost on engine concerned. (Change  
gear once or twice to ensure clutch is engaged).
5. Clutch burnt-out. (Engine becomes normally aspirated).

D.H. PROP + C.S.U. TYPE 5,500.



## D.H PROPELLER + C.S.U. TYPE 5,500.

### FAULTS AND SYMPTOMS.

- Mechanical:
1. Broken distributor valve spring
    - Prop takes up fine pitch position.
  2. C.S.U. Governor Spring breaks;
    - Prop goes into coarse pitch.
  3. C.S.U. Drive Shears;  
Prop. goes into fine pitch.
  4. C.S.U. Control Fractures;
    - Prop goes into coarse pitch.
  5. Sticking Control Valve;
    - Sluggish operation or surging R.P.M.

### OIL FAULTS.

1. Total loss of oil  
Prop goes into fine pitch.
2. Loss of C.S.U. Oil;
  - Prop goes into fine pitch.
3. Fruity oil seals;  
Surging R.P.M. or sluggish action.
4. Failure of C.S.U. Gaskets;  
Prop goes into fine pitch.
5. Cold oil in dome;  
Surging R.P.M. or sluggish action.

### ELECTRICAL FAULTS.

1. Pressure Cut-Out switch set too low
  - Prop. fails to feather completely

- 2). Pressure Cut-Out switch set too high.  
Prop unfeathers immediately after feathering.
- 3). Feathering button fails to snap out.  
Prop unfeathers after feathering.

### FEATHERING AND UNFEATHERING.

#### GROUND OPERATION.

- 1). Set throttle to approx. 1,000 R.P.M.
- 2). Press feathering button and release.  
The prop should feather and R.P.M. may be expected to drop to about 600 R.P.M. When feathering is complete, the button should snap out. (For normal checks the drop in R.P.M. and snapping out of button <sup>may be taken</sup> as sufficient evidence that the feathering is satisfactory.)
- 3). Allow the engine to run in the feathered condition for about 10 seconds to clear it of oil discharged from the prop.
- 4). Unfeather the prop by pressing the button and holding it in until R.P.M. cease to rise, when they may be expected to be about 800 R.P.M.
- 5). Release button and R.P.M. should return to their original value.

#### FLIGHT OPERATION FEATHERING

- 1). Turn off Master Fuel Cock.
- 2). Press Feathering Button (which will automatically hold in) and immediately;
- 3). Close throttle.

SNOWBALL M.G. CLASS 5

19. On the Plots Panel (right side)
20. 1014 mill 4.
21. Air would be drawn into the system which is damp, 4 before the silica gen wouldn't last as long.
22. White to Brown, 4 Blue to Pink.
23. Port Therelle 4.
24. To remove the moisture from the air and prevent icing up of the jets. 4
25. Beside 4 navigator's table.

ve

gr

aa

- unknown call.

aaa

bt

w - wait

K.

R-

T

eeeeeeee

✓

ve

✓

If the Master Cock is <sup>not</sup> turned off and immersed pumps are not on, air will be drawn off from carb of feathered engine to good engine, which in turn will fail. If the feathering push button fails to snap out when feathering is completed and the prop starts to rotate again, the button should be pulled out immediately. Prop can then be refeathered by pressing button again, and pulling out as soon as prop ceases to rotate.

#### UNFEATHERING.

1. Set all controls, switches, etc, to their normal starting positions, excepting throttle which should be fully closed and R.P.M lever set to minimum R.P.M.
2. Press feathering button and hold in, until R.P.M rises to about 1,000 R.P.M. then release button. The R.P.M. will then rise to their correct minimum value and prop will then be in C.S.L. control range. If engine temperatures have dropped below minimum for opening up, the engine should be left to windmill at a low speed until it is sufficiently warmed up.
3. Open throttle to zero boost, set R.P.M. as required, then open throttle lever to desired boost.

## ENGINE HANDLING.

When all engines are running the F/E is to say,  
"All engines running," and is to:-

- (1) Switch off Boostor coil.
- (2) Check oil pressures.
- (3) Ensure Main switch is to FLIGHT 15° Oil 60° Coolant.
- (4) When each engine is sufficiently warmed up, the F/E is to say "Mbd Inves ready for running)

The Pilot repeats and engines are run as follows:-

- (1) Check Mags at Slow Running for functional check.
- (2) Open Throttle to zero Boost and exercise Prop.  
Note Maximum R.P.M.
- (3) Select 2,000 R.P.M.
- (4) Open up to +4 and R.P.M. should remain constant.
- (5) Select Max. R.P.M. Boost should remain constant.
- (6) Open Throttle to the gate and check Static R.P.M. and Boost 2850 + 9.
- (7) Open Throttle through gate and check T.O.B. and Rev.
- (8) Throttle back to gate and check mags Max drop 100RPM
- (9) Throttle back to zero Boost and test 2 speed Blower  
Drop in R.P.M. Approx 50 - 75.
- (10) Throttle back to 12,90 R.P.M. and close throttle suddenly to check slow running.

On all engines the F/E will report:-  
ENGINES O.K. or otherwise.

shout "Brace for Ditching." and disconnect  
Intercom.

10. Wait for 2 impacts.

AFTER DITCHING.


1. Leave by mid-escape hatch taking the  
axe, and assist the dinghy out of its  
stowage.


2. Get the dinghy water borne. (Navigator helps)

3. Control the dinghy from the wing.

4. Board the dinghy when all the crew  
are on except the pilot.

D.H. Hydrodynamic Prop. Wiring System.





STROMBERG CARB. P.D.16B/1

This carburetor is of the pressure injection type in which the fuel is sprayed into the induction system under pressure. The carb. is not prone to icing up and needs no heating also is unaffected by the altitude of aircraft, &

CONSISTS OF 5 MAIN ASSEMBLIES:

1. Throttle body; which houses main and boost venturi's, and throttle butterflies.
2. Adaptor; housing spray nozzle valve and accelerator pump.
3. Fuel regulator unit; consisting of chambers A, B, C, and D, and fuel receiving chamber
4. Fuel controlling unit: houses metering jets and power enrichment device.
5. Altitude Mixture Control.

OPERATION:

When the engine is running the difference in pressure between air intake (impact tubes) and boost venturi is communicated to chambers A and B, and acts on the diaphragm attached to the poppet valve. The valve will open until the pressure D acting on the second diaphragm is sufficient to balance the valve. Pressure in chamber C is maintained constant at "5 lbs/ft<sup>2</sup>" by the spray nozzle valve. The pressure in chamber D will cause

some certain rate of flow of fuel through the metering jet sufficient for the amount of air entering engine, as the throttle is opened, the pressure difference between A and B will increase thus opening the poppet valve further and increasing the pressure in chamber D. The rate of fuel flow through the jet will increase thus keeping the mixture strength constant. At Slow Running the pressure difference between A and B is insufficient to open the poppet valve. The Idle Spring is so arranged that at engine speeds below approx 1500 RPM it holds the poppet valve open. The fuel flow is now regulated by the idle needle which is linked to the throttle butterflies. The idle needle can be adjusted to regulate the slow running mixture strength, and the slow running RPM can be varied by eccentric throttle stops. The idle spring adjustment must NOT be adjusted.

The metering jet (auto lean) gives an economical mixture and therefore enrichment is needed for high power output conditions. The enrichment valve is attached to a diaphragm subject to chamber D. pressure. At any power output corresponding to that obtained with 2650 + 7% chamber D. pressure is sufficient to open enrichment valve and allow an extra supply of fuel to flow

through enrichment jet A to the spray nozzle valve.

#### ALTITUDE MIXTURE CONTROL.

The bellows are subject to air intake pressure and as the aircraft climbs, will expand thus lowering the tapered needle into the duct leading from impact tubes to chamber A.

This has the effect of decreasing the pressure difference between A and B, which in turn will decrease the pressure in chamber D, thus reducing fuel flow through the jet.

The bellows are part filled with oil, to damp out vibration, and part with Nitrogen at approximately normal sea level pressure to make it sensitive to changes in temperature.

#### ACCELERATOR PUMP

When the throttle is opened the pressure above butterflies will increase, this increase is felt on a diaphragm which is forced down to open a valve and allow an additional supply of fuel to engine. As the body of the pump is drained of fuel the valve gradually closes. There are no mechanical connections between throttle lever and accelerator pump.

## S.U. CARBURETTOR A.V.T. 40/192

A duplex twin up-draught carburettor combines the following features;

### DIFFUSER SYSTEM

Normal action supplied with correct quantity of fuel from the variable main jets.

### PRESSURE BALANCE.

To maintain a equality set of pressure between air intake and sealed float chambers.

### SLOW RUNNING.

Calibrated jet in float chamber supplies fuel to the multiple nozzle in float chamber and helps to obviate flat spots during first opening of the throttles.

### ACCELERATOR PUMP.

Supplies extra fuel necessary for acceleration, simultaneously with opening of throttles.

### VARIABLE MAIN JETS.


Two aneroid controlled tapered needles, control the fuel flow of main jets, the port controls the variation in boost pressure, starboard for variation in atmospheric pressure.

ENGINE HANDLING.  
TAKE-OFF DRILL.

Pilot	F/E	PAUSE	ACTION BY	ACTION.
RUNNING UP.	RUNNING UP.			
O.K. FOR TAKE-OFF	O.K. FOR TAKE-OFF		5	Pilot Open throttle against brakes to clear engine. +10 <sup>o</sup> Boost
		S		Pilot Release brakes and opens throttles slowly through gate to +14 boost.
		E		F/E Checks all boost and revs for 3000+14
		O		NAV. Watches fuel pressure warning lights. If light shows turns cock to other tank.
AT 100' or over droone boundary.				
WHEELS UP	WHEELS UP	N	F/E	Selects Wheels Up
CLIMBING	CLIMBING	D	F/E	Reduces RPM to 2850. Boost to +9.
FLAPS UP	FLAPS UP	S	F/E	Selects Flaps Up gradually.
ECONOMICAL	ECONOMICAL		F/E	Reduces RPM to 2650.
CLIMB	CLIMB			Throttles to +4
				Pilot D.R. Compass to Nairobi after 5 mins
				F/E On reaching 2,000 ft switch off fuel booster pumps.

MAXIMUM CLIMB 2850+9

1 HR. LIMIT.



CONDITIONS OF CLIMB


500/600'/min.

2850+9  
2650+7  
2650+6  
2650+5  
2650+4

220/300'/min.

## ECONOMICAL CLIMB. 2650 ft

No LIMIT.



MAX. ECONOMICAL CLIMB.

2650 +7 NO LIMIT

CLIMB CAN STILL BE  
MAINTAINED BUT BOOST  
WILL FALL.

16,500' - - - F.T.H. "S" GEAR:

12,500' - - - +4 CHANGE TO S GEAR.

9,500' - - - F.T.H. "M" GEAR.

8,000' - Max. Control Height.

+4 CHANGE TO S GEAR.

+7 MAINTAINED BY EDGING THROTTLES  
FORWARD MANUALLY  
OPENING BUTTERFLIES.

RELAY PISTON MOVES FORWARD

MAINTAINING +7 Boost as we climb.

↓ N D X

## HIGH LEVEL CRUISING.

ABOVE 3,000'



M - Outwards. 170

M - Inwards. 160

S = 160 inward or  
outward.

3000' ft.

For Range Flying Conditions use  
High Level Cruising Conditions between  
recommended altitude of 8,000 and 16,000'.

## LOW LEVEL CRUISING.

BELow 3,000'



3000'



1. THROTTLES TO GIVE +4lbs.
2. MINIMUM. R.P.M.

 N  Ignore I.A.S.

## ENDURANCE FLYING.

BELOW 3,000'


1. THROTTLES SET TO GIVE 135IAS.
2. R.P.M. TO MINIMUM.

FLY LOW, FLY SLOW.

Flaps can be used if required.

Engines may be cleared at intervals.

## DESCENDING ON 3 OR 4 ENGINES.



THROTTLES AT GATE.


R.P.M. TO GIVE 160 I.A.S.


If in 'M' gear, Revs are 2500 or more  
 then change to 3 gear and adjust R.P.M. to  
 give required I.A.S.  
 3000'

THROTTLE TO GIVE +4  
 R.P.M. AT MINIMUM.

DESCENDING ON 2 ENGINES.

THROTTLE AT GATE R.P.M. TO GIVE 160 I.A.S.



OPERATIONAL CLIMB.A.U.W. EXCEEDS 60,000

3000 +14.

Altitude - Boost to 9.

Revs to 2650

Boost +4.

Edge throttle to gate

Boots begin to fall

Change to 8.

Boost to 6 lbs.

If climb is continued after setting course, adjust speed with altitude

At Target.

Revs 2850.

All Pumps ON

After Target.

Control Airspeed with Revs.

Descend

Throttles at gate.

Obtain Speed. with R of Descent  
and Revs.

M or S.

155 - 160 Light

165 - 170 Heavy

S and 1600 ft.

200  
225 250  
2

19. (a) out. (b) out. (c) out. (4)
14. Pull the clutches out. (4)
15. Get throttle. (4)
13. To test whether or not the clutches are properly in. (4)
14. By turning the altitude control anti-clockwise. (4)
15. (a) The main switch is (4). 1/5 True.
16. Main switch ON. — the other one at setting.  
(b) Main switch on (4) the other at setting.  
(c) Main switch on - the other at setting.
17. Set the barometric scale by means of the knob to the pressure of the day. The needles should read zero. Tolerance  $\pm 50$ ' (4)
18. (a) Zero.  
(b) zeros (4)  
(c) to the magnetic compass reading  
(d) every 15 minutes.

98%


SNOWBALL M. G.  
CLASS 5

4. The nose would lift and the tail would in relation appear heavy. This would cause the elevator servo motors to lower the elevators to lift the tail and keep the a/c - in level flight. (4)
3. It would affect the rudder controls by trying to pull yaw, the auto controls would then operate and straighten the aircraft. The rudder (2) would be constantly to one side you could tell by the turn indicator until the auto controls corrected it.
3. 10 hrs engine running, after each operational trip. (4)
4. The servo motors (4) jammed.
5. The altimeter (4) would read high.
6. All altimeters air speed indicators climb & descend (4) indicator, bomb sight.
7. Emergency. (4)
8. All except the (4) bank pointer in the turn & bank indicators.
9. (a) pilot head and static vent.  
(B) static vent. (4)  
(C) static vent

147  
SNOWBALL


No 7

① 10,000  
1,000




1/1. C.O PULLED. 3,000 +14 M.

② 2,000




2850 +9 M.

③ 6,000




2650 +7 M.

④ 8,000




2650 +4 M

⑤ 11,000




2850 +9 S.

⑥ 12,000




~~2850 +10 S~~ C.O.P.

⑦ 17,000



2850 +9 S.




Secretary,  
R.M.F. Schoon

WOODFORD


NE. STOCKPORT.

CHESHIRE.


F/F/E Notes for  
"LANC" AIRCRAFT.



## LANDING PROCEDURE.



## MIS- LANDING.



CRUISING POWER.

## ENGINE DRILLS.

STARTING. LANC. 3.

G/F to Ground.

Select No. 1 tanks

Booster Oil ON.

Magneto ON.

I.C.O. to I.C.O. position. N.B. Check Brake Pressure.

Throttles  $\frac{1}{2}$  open.

R.P.M. Levers. - Fine

No 1 Boosto Pump ON.

O.K. for Priming.

Green Lights ON.

Master Fuel Cocks ON. for engine to be started.

Contact.

I.C.O. to Engine ON when engine picks up.

Mk. I. Aircraft.

Same with the exception of I.C.O's.

Operational Run-Up.

Warm Up at 1200 Revs.

Test for Dead Mag.

Temp. 15° Oil. 60° Coolant Run-Up.

OPEN RAD FLAPS.

Throttle to Zero Boost.

Exercise the Prop. Min - 1800 R.P.M.

Select 2300 R.P.M.

Boost up 1 and down 1.

Select +2. Move revs 100 each way  
Boost should remain constant.  
Revo Fully Fine. Throttles at gate  
2910-3000, +9.

Test for Mag. Drop. Max. 150.

Test T.O. Boost and Revs.

3,000 +14.

Select 0 Boost.

Test Two Speed Blowers.

Throttle Back to Slow Running 600-700

Select 1200 R.P.M. for Feeding.

### FEATHERING DRILL.

Throttle Back.

Petrol OFF. (Mk.I Master Cock. Mk.III I.C.O. off)

Press Feathering Button.

Mk. II Master Cock off

UNFEATHERING Drill. Mk. III

Master Cock ON.

I.C.O. to I.C.O. position.

Magneto ON.

Throttles  $\frac{1}{2}$  open.

R.P.M. fully coarse.

Press Feathering Button.

I.C.O. to Engine ON when R.P.M. reach 800.  
1500-1800 R.P.M. take fingers of f. Button.

Jumps 65° 60°

Synchronise Engines.

Paddle Blades  
release Button  
at 1000 Revs

Over-Primed.

Turn off Fuel.

Mags off.

Open throttle.

Press Starter Button

Stopping.

Test for Mag. Drop.





Throttle Back.

Petrol off. I.C.O. - Master Books  
<sup>(W)</sup> <sub>(I)</sub>

Open throttle.

Mags OFF.

I.C.O to Engine ON.



<u>Lanc 3.</u>	"Y"
A'UW	A'UW.
65000	65000
TAREWEIGHT 36000	36000
OIL 122 GALS. 1000	1100
TE.L 2,700	<u>3,400</u>
Disposal 25,200	24,500'

200 gals + track miles  
94.

Max. Landing weight - 56,000 lbs. 63,000

### Cock Pit Checks.

Remove Locks,

Test controls in all directions

Brakes ON. 150# 80 lbs each brake.



External Warning Lights.

Fix E.I.

50 363 530 580 562 114  
CBC.

343 450 480 343.

Water gauge No lights  
 100 480 343



Change tanks. Note No. - O.K.


To 3000 +14. Whee up 100'. 2850 +9 Flaps up 800'.  
 Select 2650 +4 climb to 8000! Pump off 2000  
 level out at 8000'. Put throttle to idle, control  
 RPM up to give R.A.S.

When convoy is reached fly low with 1800 Revs.  
 Boost to give 135 T.A.S. Engines can be  
 cleared at intervals if necessary. Select  
 250 +4 climb to 10,000'.

At 10,000' T.A.S. Boost to give R.A.S.  
 Fly back to base, gradually descending and  
 lowering RPM to give Reg. A.S.

Landing - all pumps on. Select tanks with most fuel.  
 Select 2850 +9. Flaps down as required.

3. Increase Speed, decrease  $\frac{1}{2} \rho A$   
Drag and Speed



Parasitic Drag is the form drag, or the drag for which there is no lift.

Induced Drag - is drag-induced with the amount of lift, and depends on  $\frac{1}{2} \rho A$   
 Optimum Angle means minimum drag.

Max Range - Max AMPG = Economical Speed

Recommended Speed - high AMPG - but better control

P. E. Power

RH RV Pilot Jam Breaker On

ONTO OKTO Pilot Open to 3000 rev Engine - Checks gauge  
 looks out side note

Full Power Eng 8

50

42 128  $\times \frac{1}{4}$  256 85%  
 36 750 3

128-150 3 85%

## PERFORMANCE THEORY

Range : distance travelled on a given load (2000 lb)

Average A.P.P.G. =  $\frac{\text{Air miles travelled}}{\text{Gallons used}}$

1st miles possible = AMPG attained  $\times$  gallons available

Absolute AMPG =  $\frac{TAS}{GPH \text{ in use}}$

" Track MPG =  $\frac{\text{Track Speed}}{GPH \text{ in use}}$

Average T.MPG =  $\frac{\text{Track miles}}{\text{Gallons used}}$

### Air Speed

- I.A.S. - Reading of the A.S.I. = pressure developed.

R.A.S. - I.A.S. - Position error

T.A.S. = R.A.S.  $\times$  Altitude Factor.

Track Speed = T.A.S. +  $\frac{\text{Head}}{\text{Tailwind}}$ .

Lift and Drag } depend on  $\left\{ \begin{array}{l} + I.A.S \\ \text{Airspeed } \\ A.o.f.A \end{array} \right\}$  decided the I.A.S.

- A constant T.A.S. means the same lift and drag at any altitude provided the A.o.f.A is constant.

Lift, Speed and Angle of Attack.


1. A High Speed needs a small A.o.f.A.

2. " Low " " large "

Reduction of weight. (Bomber Game)

1. Same Speed, decrease A.o.f.A.

2. Reduce " same A.o.f.A



Remove bobbin from rear tunnel Cut off Valve.

Check Fuel & Oxygen bottle at rear of draught proof door.

Fuel & Oil Dipssticks, crank-case for necessity.

Check Fuel, Oxygen bottle at mid-Uppers Tunnel

Remove bobbin from COV

Check

$$\begin{array}{|c|c|} \hline 2650 + 7 & 2850 + 9 \\ \hline 8000 & 1000 \\ \hline \end{array}$$

MC R 95200  
0.9

10	0	0
10	0	0
10	0	0
10	0	0
10	0	0

MSC



2650

FIT 7 ECV

1

2

3

4

Max T.O. 3000 +14 Coolant Out 15 - 5 min. - 100 ft

" Climbs 2850 + 9 125° 90° - 1 hr limit

" Continuous 2650 + 7 125° 90°


" Constant 3000 + 9 135° 105°

14 + 16 will not pull





Sea level in feet +4

	1800	2000	2200	24000	2650
D.H.P.	631	687	737	777	812
G.P.A	418	447	477	513	566
R.M.	15.1	15.3	15.4	15.1	14.35



# MERLIN "M" GEAR.



ALTITUDE.  
THS. or FT.

- ② Stand pump.  
Normally,  Being for,  Being for the pump.
- ③ Emergency  
④ Control valve. directs oil to either cylinder cycle of fluid.  Being for the returning surplus oil from the tank.  Being for the reservoir.  Being for a pump.
- Hydro flask has a valve lock.
- Transforms water pressure into mechanical force.

Simple system incorporating an engine driven pump.



Advantages of hydraulics over mechanical systems are as follows

- ① Ease of operating. (by utilizing area of fact.)
- ② Easy remote control (through small bore pipes.)
- ③ Small number of moving parts.
- ④ Self lubricating and non corrosive.
- ⑤ Light in weight.

Oil is used in hydraulic systems because

- ① Oil is compressible.
- ② Oil lubricates.
- ③ Oil has low freezing point, and high boiling point.

Two types of oil can be used in hydraulic systems depending on the manufacturer.

The majority use oil freezing type A

Cessna only uses a special oil (Lockheeds)

Anti-freezing oil - A mineral base oil.

Must not be used with rubber glands, and seals. Use cyanoacrylate rubber instead.

Lockheeds oil.

Used only in Lockheed systems. - A vegetable base oil is manufactured for use with pure rubber glands.

Four components essential to any hydral system

#### ① Reservoir

Is volume of oil which allows for ② the displacement of the air in the tank. ③ dry minor leakage. ④ Thermal expansion. The reservoir is always vented to atmosphere to allow for the rise and fall of oil levels. To allow for varying atmospheres at different altitudes